AIMotor driver 220V 380V Operate manual

Safety notes

Danger means that when used incorrectly, it will lead to danger and personal injury.



Note: When used incorrectly, it will cause danger, personal injury and

possible damage to equipment.



Prohibition: It means strictly prohibiting the behavior, otherwise it will lead to equipment damage or can not be used.

1.Use occasion



It is forbidden to use the product in flammable and explosive occasions, which can easily cause injury or fire.

It is forbidden to use the product in places with humidity, direct sunlight, dust, salt and metal powder.

Wring

DANGER

- Do not connect 220V driver power to 380 power supply, otherwise it will cause equipment damage or fire. •
- Please grounding terminal $\stackrel{(l)}{=}$ reliably. Poor grounding may cause electric shock or fire. •
- Do not connect the output terminal of driver U-V-W motor to three-phase power supply, otherwise it will cause • casualties or fire.
- Driver UVW motor output terminal and motor connection terminal UVW must be connected correspondingly, • otherwise the motor may cause equipment damage and casualties due to speeding.

• Wiring please refer to wire wiring, otherwise it may cause fire.

Operation



- Before starting operation, please make sure that you can start the emergency switch and shut down at any time.
- When commissioning, please separate the servo motor from the machine. After the action is confirmed, the motor is installed on the machine.
- After the servo motor stops and restores instantaneously, do not approach the machine. The machine may suddenly start again.
- Do not switch on or off the power frequently, otherwise it will cause overheating inside the driver.

Function



- When the motor is running, do not contact any rotating parts, otherwise it will cause casualties.
- When the equipment is running, it is forbidden to touch the driver and motor, otherwise it will cause electric shock or scald.
- When the equipment is running, it is forbidden to move the connecting cable, otherwise it will cause personal injury or equipment damage.

Chapter 1 Product introduction

| ······································ | | | | | | | | | | | |
|--|------------------------|---|---|---|---|---|--|--|--|--|--|
| Driver Model | | D-AIS | D-AIS | D-AIS | D-AIS | D-AIS | D-AIS | D-AIS | D-AIS | D-AIS | D-AIS |
| | | 22020A | 22020B | 22020C | 22030A | 22050A | 38035A | 38035B | 38050A | 38075A | 380100A |
| Module Current(A) | | 20 | 20 | 20 | 30 | 50 | 35 | 35 | 50 | 75 | 100 |
| 1 | Output | 12.8 | 12.8 | 12.8 | 19.8 | 31.8 | 22.3 | 22.3 | 31.8 | 48 | 63.6 |
| 2 | Current | 6.4 | 6.4 | 6.4 | 9.9 | 15.9 | 11.1 | 11.1 | 15.9 | 24 | 31.8 |
| 3 | (A) | 4.3 | 4.3 | 4.3 | 6.6 | 10.6 | 7.4 | 7.4 | 10.6 | 16 | 21.2 |
| | rent(A) 1 2 3 | rent(A) 1 Output 2 Current 3 (A) | D-AIS 22020A rent(A) 20 1 Output 12.8 2 Current 6.4 3 (A) 4.3 | D-AIS D-AIS 22020A 22020B rent(A) 20 1 Output 2 Current 3 (A) | D-AIS D-AIS D-AIS 22020B 22020C rent(A) 20 20 20 20 1 Output 12.8 12.8 12.8 2 Current 6.4 6.4 6.4 3 (A) 4.3 4.3 4.3 | el D-AIS D-AIS D-AIS 22020B 22020C 22030A rent(A) 20 20 20 30 30 30 3 12.8 12.8 12.8 19.8 3 4.3 4.3 4.3 6.6 | el D-AIS D-AIS D-AIS D-AIS 22020A 22020B 22020C 22030A 22050A rent(A) 20 20 20 30 50 1 Output 12.8 12.8 12.8 19.8 31.8 2 Current 6.4 6.4 6.4 9.9 15.9 3 (A) 4.3 4.3 4.3 6.6 10.6 | $\begin{array}{c c c c c c c c c c c c c c c c c c c $ | $\begin{array}{c c c c c c c c c c c c c c c c c c c $ | $\begin{array}{c c c c c c c c c c c c c c c c c c c $ | $\begin{array}{c c c c c c c c c c c c c c c c c c c $ |

Servo driver technical specifications

| Input power | | D-AIS220 series drives single-phase or three-phase 220VAC (voltage fluctuation -15% \sim +10%), 50 Hz /60Hz | | | | | |
|-------------------------|-----------------------|--|--|--|--|--|--|
| mput | power | D-AIS380 series drive three-phase 380VAC (voltage fluctuation -15% \sim +10%), 50 Hz /60Hz | | | | | |
| Operating | temperature | Working: 0° C ~ 55 $^{\circ}$ C Storage: -20 $^{\circ}$ C ~ +80 $^{\circ}$ C | | | | | |
| environment | humidity | Less than 90% (no condensation) | | | | | |
| control | method | (1) position control (2) speed control (3) torque control (4) communication control (5) Analog control | | | | | |
| Regenerativ | e brake | Built-in (When the built-in brake resistance power is not enough, external high-power brake resistance can be connected) | | | | | |
| | | Speed frequency response: ≥200Hz | | | | | |
| | | Velocity fluctuation: $< \pm 0.03$ (load $0 \sim 100\%$) : $< \pm 0.02 \times (0.9 \sim 1.1)$ supply voltage | | | | | |
| Control ch | aracteristic | Speed ratio: 1:5000 | | | | | |
| | | Receiving pulse frequency ≤300kHz | | | | | |
| Control input | | 01, servo enable; 02, alarm clearance; 03, Multistage run instruction switching 1; 04, Multistage run instruction ching 2; 05, Forward overrange switch; 06, Reverse overrange switche; 07, Speed forward ; 08, speed reverse; nulti-segment position running command was enabled; 10. External origin switch; 11, origin restoration function is enabled; 12. EMERGENCY STOP; 13. Clear the position deviation counter; 14. Impulse command disable;15.Set the current position as the origin;16.analog input | | | | | |
| Control output | | 01, the servo is ready to output; 02. Complete the output of positioning; 03, fault alarm output 04. Confirm the origin back to zero output; 05, electrical confirmation back to zero output; 06, torque to the output; 07, the speed reaches the output;08.Brake output control | | | | | |
| Position | a control | Input mode: Pulse + direction; AB orthogonal pulse; CW/CCW dual pulse The electronic gear ratio :1 ~ 32767/1 ~ 32767 (The default is 131072:1000, that is, 1000 pulses per circle) Feedback pulse:131072 Pulse/revolution | | | | | |
| speed | control | 4 internal speeds (switched by combination of SC1 and SC2 input signals) | | | | | |
| Accelera deceleratio | ation and on function | Setting Acceleration and Deceleration Duration 1 to 10000 ms (0 r/min to 1000 r/min) | | | | | |
| Monitor | function | Speed, current position, command pulse accumulation, position deviation, motor torque, motor current, bus voltage, Rotor absolute position, command pulse frequency, running state, input and output terminal signals, etc | | | | | |
| protect func | tion | Overspeed, overvoltage and undervoltage of the main power supply, overcurrent, overload, abnormal braking, | | | | | |
| | | abnormal encoder, abnormal control power supply, abnormal position, etc | | | | | |
| Applicable | load inertia | Less than 5 times the inertia of the motor rotor | | | | | |
| RS485 1 | function | ① Communication control position ② communication control speed ③ communication control torque Follow the standard Modbus-RTU protocol | | | | | |

(3 **)**

Chapter 2 Installation

2.1 D-AIS22020A(200W~1KW) servo-drive external dimensions



2.2 D-AIS22030A(1.0KW to 2.6KW) servo-drive external dimensions



[

2.3 D-AIS38050A, D-AIS380100A(1.0KW to 3KW) servo-drive external dimensions



2.4 D-AIS380150A, D-AIS380200A(3.7KW to 11KW) servo-drive external dimensions



2.6 Standard wiring diagram2.6.1 Position mode wiring diagram



Position mode wiring diagram

PS: Just USE RS485 communication have encoder signal output.

2.6.2 Speed/Torque mode wiring diagram

2.6.2 Control signal terminal DB44 interface definition



Speed/torque mode wiring diagram

PS: Just USE RS485 communication have encoder signal output.

2.6.3 Speed/torque mode wiring diagram



Note: Control signal terminal detailed interface function description please see the next page

8

]

2.6.4 Control signal input/Output Terminals (44-core terminals)

The applicable control mode is referred to as: P stands for position control mode; S stands for speed control mode; T stands for torque control mode; ALL Indicates all control modes.

| Terminal No | Signal Name | Mark | Mode | Function | | | |
|----------------|---|---------------|------|---|--|--|--|
| 41 | Command pulse 24V positive end | PUL-H | | ① Determine the Angle and speed of the motor. | | | |
| 32 | Command pulse 5V positive end | PULS+ | Р | Select the corresponding port according to the pulse voltage. When the control voltage is 12-24V, PUL-H and PUL- are the pulse | | | |
| 33 | Instruction pulse input negative end | PULS- | | input terminals. | | | |
| 42 | nstruction direction 24V positive end | DIR-H | | 1.Determine the rotation direction of the motor. | | | |
| 34 | Instruction direction 5V positive end | DIR+ | ALL | 2.Select the corresponding port based on the directional voltage.3.When the control voltage is 12-24V, the DIR-H and DIR-bit | | | |
| 35 | Instruction direction input negative end | DIR- | | directions are input terminals. | | | |
| 18 | common end of the digital input terminal | СОМ | ALL | The common end of the input terminal is used to drive the input optocouple, and is connected to DC 12V ~ 24V (common positive NPN connection) or 0V (common negative PNP connection), the current is \geq 100mA | | | |
| 10 | Digital input terminal 1 | DI1 | ALL | The terminal function depends on the user's I/O input function selection. Factory default I/O input function select 01 (Servo enable control SON) | | | |
| 40 | Digital input terminal 2 | DI2 | ALL | The terminal function depends on the user's I/O input function selection. Factory default I/O input function select 02 (Fault and warning reset ALM-RST) | | | |
| 39 | Digital input terminal 3 | DI3 | ALL | The terminal function depends on the user's I/O input function selection. Factory default I/O input function select 34 (EmergencyStop) | | | |
| 38 | Digital input terminal 4 | DI4 | ALL | The terminal function depends on the user's I/O input function selection. Factory default I/O input function select 18 (click JOGCMD+ forward) | | | |
| 11 | Digital input terminal 5 | DI5 | ALL | The terminal function depends on the user's I/O input function selection. Factory default I/O input function select 19 (click JOGCMD-in reverse) | | | |
| 15 | Digital input terminal 8 | DI8 | ALL | The terminal function depends on the user's I/O input function selection. | | | |
| 12 | Digital input terminal 9 | DI9 | ALL | The terminal function depends on the user's I/O input function selection. | | | |
| Terminal No | Signal Name | Mark | Mode | Function | | | |
| 8 25 | Digital output terminal 1 | DO1+ DO 1- | ALL | The function of the terminal depends on the user's I/O output function. Factory default I/O output function Option 1 (Servo ready S-RDY) | | | |
| 26 27 | Digital output terminal 2 | DO 2+ | ALL | The function of the terminal depends on the user's I/O output function. Factory default I/O output function select 11 (fault alarm output ALM) | | | |
| 28 | Digital output terminal 3 | DO 3+ | ALL | The function of the terminal depends on the user's I/O output function. | | | |
| | 1 | 205 | (| 9 | | | |

| | | | | Factory default I/O output function select 5 (locate complete COIN) |
|-------|---------------------------|--------|-----|---|
| 30 | | DO4+ | | The function of the terminal depends on the user's I/O output function. |
| 31 | Digital output terminal 4 | DO 4- | ALL | Factory default I/O output function select 18 (torque to output |
| | | 201 | | ToqReach) |
| 43 | | DO5+ | | The function of the terminal depends on the user's I/O output function. |
| 44 | Digital output terminal 5 | DO5- | ALL | Factory default I/O output function select 19 (Speed to output V-Arr) |
| 14 | Drive incide 5V | 5 Vout | | Used only as an analog input, the external power supply can be omitted |
| 14 | Drive mside 5 v | 5 Voui | ALL | in analog mode |
| 20 | Simulate speed or torque | AS+ | C/T | • Differential mode, input impedance 10k Ω , input range -10V ~ |
| 19 | instruction input | AS- | 5/1 | +10V. |
| 22 | AGND | AGND | S/T | • Simulates the input ground wire |
| 23/24 | GND | GND | ALL | • Ground wires for digital signals |
| Shell | FG | FG | ALL | Shielded ground terminal |

2.6.5 Encoder signal input terminal (9-core terminal)

| Terminal No | Signal Name | Mark | Mode |
|----------------|-----------------------|------|---|
| 1 | 5V Power | +5V | Servo motor encoder with +5V power supply and public ground; When the cable is |
| 2 | Power common | 0V | long, multiple lines should be connected in parallel to reduce line voltage drop. |
| 4 | Encoder communication | SD+ | Connected to absolute encoder SD+ phase |
| | signal positive end | | |
| 5 | Encoder communication | SD- | Connected to absolute encoder SD- phase |
| | signal negative end | | |
| Shell | Frame Grounded | FG | Shielded ground terminal |

3.1 Panel shows

The operating interface of the servo driver is composed of 5 LED digital tubes and 5 keys, which can be used for the state display and parameter setting of the servo driver. The interface layout is as follows:



Key function description

| Button | Button | Function |
|--------|----------|--|
| | NODE | |
| M | MODE | Switch the status monitoring mode/parameter mode/alarm mode and return to the previous |
| | | menu. |
| • | multiply | Add monitor code, parameter number or set value, long press can increase quickly. |
| • | Reduce | Reduce the monitoring code, parameter number or set value, long press can quickly reduce. |
| • | Shift | When setting parameters, press this key to move the selected flicker bit to the left by one. |
| SET | Confirm | Go to the next menu, or save the Settings. |

Numerical indication

The numerical value USES 5 digital tube displays. The minus sign in front of the numerical value indicates a negative number. If it is a 5-digit negative number, all decimal points are lit to indicate a negative number. Some display items are preceded by an affix character, and if the number of digits is too long to occupy the position of the prefix character, the prefix character will not be displayed, only the value.



-1234, If a negative number is less than 4 digits, a minus sign is displayed in front of it 1.2.3.4.5, -12345, 5 digits negative, all decimal points lit to indicate negative numbers

3.2 Panel Display

Panel display

When the servo drive is running, the display can be used for servo status display, parameter display, fault display and monitoring display.

- Status display: Display the current status of the servo, such as the servo is ready, the servo is running, etc.
- Parameter display: display parameters and parameter Settings.
- Fault display: display servo fault and warning.
- Monitoring display: display the current operating parameters of the servo.

The panel displays the switching method



Motor quiescence

The panel shows a schematic diagram of the switching method

- When the power is on, the panel display immediately enters the status display mode.
- Press "MODE" key to switch between different display modes.
- When the status display, set H02.32 to select the monitoring target parameters, the motor rotates at the same time, the display automatically switches to the monitoring display, the motor is quiet

After the stop, the display automatically restores the status display.

- When parameter display, set H0B group parameters to select pre-monitored target parameters, you can switch to monitoring display.
- In case of failure, immediately switch to the fault display mode, at this time, the 5-bit digital tube flashes synchronously. Press the "SET" key to confirm that the fault stop nixie blinks and then Press MODE to switch to the parameter display mode.

Status display

| Display | Name | Display occasion | Description | | |
|-------------|------------------|-----------------------------------|---|--|--|
| | Reset | Servo power-on moment | The drive is in the initialization or reset state. | | |
| r + + + + | Servo | | Wait for initialization or reset to complete, and | | |
|))) | initialization | | automatically switch to other states. | | |
| | Nrd | Servo initialization is complete, | Because the main circuit is not powered on, the servo | | |
| nrd | Servo not ready | but the drive is not ready. | is not running | | |
| | | | | | |
| | Rdy | driver is ready. | servo driver is in the running state, waiting for the | | |
| rdy | Servo ready | | host computer to give the servo enable signal | | |
| | | | | | |
| | Run | servo enabled signal is active. | servo driver is running. | | |
| гип | Servo is running | (S-ON is ON) | | | |
| | | | | | |

Parameter display

According to the different parameter functions, the servo is divided into 19 groups of parameters, and the parameter position is quickly positioned according to the parameter groups. For the parameter list, see See the "Parametric Functions" section.

• Parameter group display

| Display | Display | Content | | |
|---------|-------------------------------|---|--|--|
| HXX.YY | parameter group identifier | XX: Parameter group number (in decimal). YY: offset (hexadecimal) in parameter | | |
| | | group. | | |

For example, H02.00 The following information is displayed:

| | | | |
|---------|-------------------|--|--|
| Display | Display | Content | |
| H02.00 | Parameters H02.00 | 02: indicates the parameter group number 00: indicates a bias within the parameter group | |

3.3 Parameter Settings

The servo drive parameters can be set as follows

1. Press the [M] key in the menu of the first layer to switch to the parameter setting mode of "H00.";

2. Select different parameter groups H00 ~ H12 with 【▲】 and 【▼】 keys, and press 【 】 key to enter the "Parameter number" selection menu on the second layer;

3. Select different parameter numbers with **[\]** and **[\]** keys. Press the **[**8**]** key to display the parameter

value. The lowest parameter value flickers. Use the **[]** key to move the flicker, and use the **[] , [V]** keys

to change the parameter value.

4. Press **[8]** to save the modified value. The modified value will be immediately reflected in the control.

5. Then press $[\blacktriangle]$, $[\blacktriangledown]$ keys can continue to modify the parameters, after the modification is completed, press [M] key to return to the parameter selection menu.

6. If you are not satisfied with the value being modified, do not press **[8]** to confirm, you can press **[M]** to cancel, the parameter is restored to the original value, and return to the parameter selection menu.

Chapter 3 control flow chart

Control flow graph

This system uses the tree structure setting, step by step to expand the branch, in the application of this product, please refer to the following table design; The system is structured from left to right \rightarrow

| | | | Instruction source =0 Derived from internal parameters | H06_03 Set speed + Enable Start/stop control | | | |
|----------------------------------|--|--|--|--|--|--|--|
| | | Speed command selection H06_02 | Instruction source =1 Derived from analog AI1 | External analog voltage input DI Association SON Enables the start and stop control | | | |
| | =0 Speed control | | Instruction source =5 Derived from internal multispeed | H12_00 Multi-speed mode selection | =0 Single cycle operation =1 cycle operation =2 DI Switchover Operation | | |
| | | | JOG Speed control | H06_04 Sets the rotational DI is associated with JOGC | speed MD± click | | |
| Control mode Selection H02_00 | Position =1 command Position selection control H05_00 | | = 0 Pulse-derived control = 2 Derived from multi-bit control | H05_15 Pulse command mode selection H11_00 Multi - segment running mode selection | =0 Pulse + directional positive logic =1 Pulse + direction negative logic =2 AB Phase pulse =0 Single cycle operation =1 cycle operation =2 DI Switchover Operation =3 Run Sequence | | |
| | =2 Torque control | Torque instruction selection H07_02(Select) | Instruction source =0 Derived from internal parameters | H07_03 S H07_19 Sets the max H07_20 Sets the max DI Association SON Enable | et torque; imum forward speed. kimum reverse speed es the start and stop control | | |
| | | ↓ H07-00 (Main) H07-01 (Auxiliary) | Instruction source =1 Derived from analog AI1 | External analog voltage input DI Association SON Enables the start and stop cont | | | |

14]

Note on parameters:

1. "Applicable mode" in the parameter table P represents position mode, S represents speed mode, and T represents torque mode.

2.Some parameters can be modified only after the motor is disabled, or after the modification, you need to power off and restart. Please pay attention to "Modification Mode" and "Effective Mode" in the parameter table.3.Communication access or control parameters Please note "Data type" and "Parameter setting range" in the parameter table.

4.1 Parameter Functions

4.1-Driver parameters(H00-H01)

| H00_00 | Description | Motor c | ode | Alter mode | Enable off | factory default | Manufacturer registration | Unit | - |
|---|-------------------|---------|------------|------------------|-----------------------------|-----------------------|---------------------------|--------------|--------|
| | Parameter range 0 | | 1073741824 | Effective way | power off and restart | Adaptation pattern | P/S/T | Data type | Uint32 |
| Manufacturer parameters, different motor manufacturer number is different, need manufacturer permission can be modified, users do not modify; | | | | | | | | | |

| | Description | Zero state of motor | | Alter | Display | factory | Manufacturer | Unit | - |
|---|--------------------|---------------------|---|------------------|----------|------------|--------------|--------------|--------|
| | | encoder | | mode | P - 00 J | default | registration | | |
| | | | | | | Adaptation | | | |
| H00_08 | Parameter range | 0 | 1 | Effective way | - | pattern | P/S/T | Data type | Uint16 |
| Manufacturer's parameters, assembly motor encoder set to zero, display parameters can not be changed; | | | | | | | | | |
| | | | | | | | | | |

| | Description | Brake s | selection | Alter mode | Enable off | factory default | Manufacturer registration | Unit | - |
|----------------------|-----------------------|-----------|-----------------|------------------|-----------------------------|-----------------------|------------------------------|---------------|--------|
| H00_02 | Parameter range | 0 | 2 | Effective way | power off and restart | Adaptation pattern | P/S/T | Data type | Uint32 |
| Manufactu modify; | urer parameters, diff | erent mot | or manufacturer | number is diff | ferent, need n | nanufacturer per | mission can be modi | fied, users d | o not |

| | Description | Rated volt | tage of motor | Alter mode | Display | factory default | Manufacturer registration | Unit | - |
|-----------|--------------------|---------------|------------------|-------------------|--------------|-----------------------------|------------------------------|--------------|--------|
| H00_09 | Parameter range | 0 | 380 | Effective way | - | Adaptation pattern | P/S/T | Data type | Uint16 |
| Manufactu | urer's parameters, | assembly m | otor encoder se | t to zero, displa | y parameters | can not be char | nged; | | |
| | | | | | | | | | |
| | Description | Motor rate | d current | Alter mode | Enable of | f factory default | Manufacturer registration | Unit | 0.01A |
| H00_11 | Parameter range | 0 | 65535 | Effective way | power of | Adaptatio n pattern t | P/S/T | Data type | Uint16 |
| Manufactu | urer parameters, c | lifferent mot | or rated current | is different, nee | ed manufact | arer permission | to modify, users do n | ot modify; | |
| | Description | Rated torq | ue of the motor | Alter mode | Enable of | f factory default | Manufacturer registration | Unit | 0.01N |
| H00_12 | Parameter range | 0 | 65535 | Effective way | power of | Adaptatio n pattern t | P/S/T | Data type | Uint16 |
| Manufactu | urer parameters, c | lifferent mot | or rated voltage | is different, ne | ed manufact | urer permission | to modify, users do n | ot modify; | |

| _ | Description | Motor rated speed | | Alter mode | Enable off | factory default | Manufacturer registration | Unit | rpm |
|-----------|---------------------|-------------------|---------------------|------------------|--------------------------|-----------------------|------------------------------|--------------|------------|
| H00_14 | Parameter range | 0 | 6000 | Effective way | power off and restart | Adaptation pattern | P/S/T | Data type | Uint1 6 |
| Manufactu | urer parameters, di | fferent mot | or rated speed is d | lifferent, need | manufacturer | permission to | modify, users do not | modify; | |

| | Description | Motor max | x speed | Alter mode | Enable off | factory default | Manufacturer registration | Unit | rpm |
|-------------------------|---|-----------------------------|---|------------------------------|----------------------------------|----------------------------------|---|----------------------|---------------------------|
| H00_15 | Parameter range | 0 | 6000 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu permission | arer's parameters, n, but not by the u | the maximu user; This pa | m speed of differe rameter serves as | ent motors is of the maximum | lifferent, whic speed limit o | ch can only be f the motor an | modified by the man d has the highest prio | ufacturer's rity. | |
| | Description | Motor mor Jm | ment of inertia | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.01kg cm ² |
| H00_16 | Parameter range | 0 | 65535 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu modify; | irer parameters, d | ifferent mot | or moment of iner | rtia is differen | t, need the ma | nufacturer's p | ermission to modify, | he user do r | not |
| | Description | Number of | f motor poles | Alter mode | Enable off | factory default | Manufacturer registration | Unit | Pole |
| H00_17 | Parameter range | 2 | 360 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| The numb | er of poles of diff | erent motor | s is different, and | the manufactu | ırer's permissi | on can be mod | lified, and the user sh | ould not mo | dify it. |
| | Description | 5 | stator resistor | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.001Ω |
| H00_18 | Parameter range | 1 | 65535 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu modify; | irer parameters, d | ifferent mot | or moment of iner | rtia is differen | t, need the ma | nufacturer's p | ermission to modify, | the user do r | not |
| | | | | Alter | | fasters | Monufacturer | | 0.01 |
| | Description | Stator inc | luctance Lq | mode | Enable off | default | registration | Unit | H |
| 1100 10 | | | | | | Adaptation | | | |

| | Description | Stator ind | luctance Lq | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.01m H |
|----------------------|----------------------|--------------|--------------------|------------------|--------------------------|-----------------------|------------------------------|---------------|------------|
| H00_19 | Parameter range | 1 | 65535 | Effective way | power off and restart | Adaptation pattern | P/S/T | Data type | Uint16 |
| Manufactu modify; | urer parameters, sta | ator inducta | nce Lq of differen | nt motors are o | different, need | manufacturer | permission to modify | y, users do n | iot |

| - | Description | Stator ind | uctance Lq | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.01m H |
|----------------------|----------------------|--------------|--------------------|------------------|--------------------------|-----------------------|------------------------------|---------------|------------|
| H00_20 | Parameter range | 1 | 65535 | Effective way | power off and restart | Adaptation pattern | P/S/T | Data type | Uint16 |
| Manufactu modify; | arer parameters, sta | ator inducta | nce Lq of differer | nt motors are o | different, need | manufacturer | permission to modify | y, users do n | ot |

| | Description | Coefficien potential | nt of line back | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.01V/ 1Krpm |
|----------|--------------------|-------------------------|---------------------|------------------|--------------------------|-----------------------|---------------------------|--------------|-----------------|
| H00_21 | Parameter range | 1 | 65535 | Effective way | power off and restart | Adaptation pattern | P/S/T | Data type | Uint16 |
| Monufact | ror noromotora di | fforont mot | ar lina haalt notan | tial as affinian | tia different | nood the menuf | acturar normission t | modify th | a usar da |

Manufacturer parameters, different motor line back potential coefficient is different, need the manufacturer permission to modify, the user do not modify;

| | Description | | ler offset | Alter mode | Display | factory default | Manufacturer registration | Unit | P/r |
|--------|--------------------|---------|------------|------------------|---------|------------------------|------------------------------|--------------|--------|
| H00_28 | Parameter range | -131072 | 131072 | Effective way | - | Adaptatio n pattern | P/S/T | Data type | Uint32 |
| | | | | | | | | | |

Factory parameters, assembly motor encoder set to zero use, users can not change;

| | Description | Motor max | current | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.01A |
|--------|--------------------|-----------|---------|------------------|--------------------------|------------------------|------------------------------|--------------|--------|
| H00_43 | Parameter range | 0 | 65535 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |

The maximum current that different motors can accept is different. Setting an illegal value will lead to heat or damage of the motor. Only the permission of the manufacturer can be modified.

Limit current output = limit torque output; This parameter, together with $H07_09/H07_10$ and manufacturer's parameter $H01_03$, is used as the actual maximum current output limit of the motor, and its low effective value is taken.

| | Description | N edition nur | MCU software edition number | | Display | factory default | Manufacturer registration | Unit | - |
|-----------|--------------------|------------------|--------------------------------|------------------|----------------|------------------------|------------------------------|--------------|--------|
| H01_00 | Parameter range | 0 | 65535 | Effective way | - | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu | urer parameters, s | software vers | ion number; Disp | lay parameter | s cannot be ch | nanged. | • | | |

| - | Description | Driver C | ode | Alter mode | Enable off | factory default | Manufacturer registration | Unit | - |
|----------------------|----------------------|--------------|-------------------|------------------|--------------------------|------------------------|---------------------------|---------------|------------|
| H01_02 | Parameter range | 0 | 65535 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint1 6 |
| Manufactu modify; | urer parameters, dif | fferent driv | er manufacturer n | umber is diffe | erent, need ma | nufacturer per | mission can be modified | ied, users do | o not |

| | Description | Driver max | current | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.01A |
|---------------|--------------------|----------------|--------------------|-----------------|------------------------------|------------------------|---------------------------|--------------|-------------|
| H01_03 | Parameter range | 0 | 0 65535 | | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufacturer | parameters, diffe | erent drivers | can output the ma | ximum curren | t is different, | setting an illeg | gal value will lead to | o motor he | ating or |
| damage, need | manufacturer pe | rmission to n | nodify, users do n | ot modify; | | | | | |
| Limit current | output = limit to | que output; | This parameter, to | gether with H | 07_09/H07_1 | 0 and manufa | cturer's parameter H | 00_43, is | used as the |
| actual maximu | um current outpu | t limit of the | motor, and its lov | v effective val | ue is taken. | | | | |

| | Description | Current s | ampling lag | Alter | Enable off | factory | Manufacturer | Unit | 0.01m |
|-------------|---------------------|-------------|------------------|------------------|--------------------------|---------------|-----------------------|--------------|------------|
| | Description | time | | mode | | default | registration | Onit | s |
| | | | | | | Adaptatio | | | |
| H01_04 | Parameter range | 1 | 10000 | Effective way | power off and restart | n pattern | P/S/T | Data type | Uint1 6 |
| Manufacture | r parameters, diffe | rent driver | current sampling | lag time is dif | ferent, need th | he manufactur | er permission to modi | fy, do not m | odify |
| the user; | | | | | | | | | |

| | Description | Driver cu resistance | rrent sampling | Alter mode | Enable off | factory default | Manufacturer registration | Unit | mΩ |
|----------------------|---------------------|-------------------------|--------------------|------------------|--------------------------|------------------------|------------------------------|--------------|--------|
| H01_05 | Parameter range | 5 | 65535 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu modify; | urer parameters, di | fferent driv | e current sampling | g resistance is | different, nee | d manufacture | er permission to modi | fy, users do | not |

| | Description | Driver cur input resis | rent amplifier | Alter mode | Enable off | factory default | Manufacturer registration | Unit | Ω |
|------------------------|---|---------------------------|----------------|------------------|--------------------------|------------------------|---------------------------|--------------|--------|
| H01_06 | Parameter range | 500 | 65535 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu modified, | Manufacturer parameters, different drivers of the current amplifier input resistance is different, need manufacturer permission can be modified, users do not modify; | | | | | | | | |

| - | Description | Driver current amplifier feedback resistance | | Alter mode | Enable off | factory default | Manufacturer registration | Unit | Ω |
|------------------------|--|--|--------------------|------------------|--------------------------|------------------------|---------------------------|---------------|--------|
| H01_07 | Parameter range | 500 | 65535 | Effective way | power off and restart | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu modified, | urer parameters, c users do not mod | lifferent driv ify; | ers of the current | amplifier feed | back resistant | e is different, | need manufacturer p | permission ca | in be |

| | Description | Driver tem threshold | perature alarm | Alter mode | Enable off | factory default | Manufacturer registration | Unit | °C |
|-------------------------|--|---------------------------|--|--------------------------------|--------------------------------|--------------------------|---------------------------|---------------|--------|
| H01_08 | Parameter range | 40 | 100 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu modify. If | urer parameter, as the set value is e | the driver o xceeded, the | verheat protection motor overheatin | threshold, ca g fault alarm | n only be mod ER.650 will o | lified by the n ccur; | nanufacturer permiss | ion, users do | not |

| - | Description | Driver bus voltage attenuation coefficient | | Alter mode | Enable off | factory default | Manufacturer registration | Unit | - |
|-----------|--------------------|---|---------------------|------------------|------------------------------|------------------------|------------------------------|--------------|--------|
| H01_09 | Parameter range | 10 | 65535 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Manufactu | urer parameters ca | n be modifi | ed only after the p | permission of | the manufactu | rer. Users do | not modify them. | | |

4.2-Basic control parameters(H02)

| | Description | Control mo | de selection | Alter mode | Enable off | factory default | 1 | Unit | - |
|---|---|--|--|---|------------------------------|------------------------|---|--------------|--------|
| H02_00 | Parameter range | 0 | 6 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Set 0: spec Set 1: posi Set 2: torq | ed mode (refer to ition mode (refer ue mode (refer to | Section 4.5 to Section 4. Subsection | / Speed Control pa 4 / Position Contr 4.6 / torque Contr | arameters); ol parameters ol parameters |);); | | | | |
| | Description | Rotation di selection | rection | Alter mode | Enable off | factory default | 0 | Unit | - |
| H02_02 | Parameter range | 0 | 1 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Set 0: CC Set 1: CW | t 0: CCW is positive direction and CW is negative direction and CW is the negative direction and CCW is the negat | | | | | | 魚方向 CW 正方向 CCW | | |

| - | Description | Enable OF | FF Select the mode | Alter mode | Enable off | factory default | 0 | Unit | - |
|---|--|--------------------------------|--------------------|------------------|------------------------------|------------------------|-------|--------------|--------|
| H02_05 | Parameter range | 0 | 2 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Set 0: free Set 1: zero | stop, keep free st speed stop, keep | ate after sto free after st | pping; opping; | | | | | | |
| Set 2: zero speed stop, keep DB state after stopping (damping state after enabling OFF, recommended for vertical load); | | | | | | | | | |

| - | Description | Delay from ON to con | n gate output | Alter mode | Enable off | factory default | 250 | Unit | ms |
|-----------|--------------------|-------------------------|---------------------|------------------|------------------------------|------------------------|------------|--------------|--------|
| H02_09 | Parameter range | 0 | 500 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Set the d | elay time when the | servo drive | starts to receive f | he input comr | nand after the | servo drive is | nowered ON | | |

Brake starting voltage Alter Manufacturer factory Description Enable off Unit 0.1V value default registration mode Adaptatio with H02_19 n pattern Effective immediat Parameter Data 4500 400 P/S/T Uint16 e effect range way type

When the real-time input bus voltage is higher than this value, start the brake

| | Description | Brake stop | voltage value | Alter mode | Enable off | factory default | Manufacturer registration | Unit | 0.1V |
|-------------|--------------------|----------------|--------------------|------------------|------------------------------|------------------------|------------------------------|--------------|--------|
| H02_20 | Parameter range | 400 | 4500 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| After the l | brake is turned on | , the real-tin | ne input bus volta | ge is lower that | an this value, a | and the brake | is turned off | | |

| | Description | minimum consumpti allowed by | power on resistance y the driver | Alter mode | Only show | factory default | Manufacturer registration | Unit | Ω |
|---------------------|--------------------|------------------------------------|--|------------------|----------------|------------------------|---------------------------|---------------|--------|
| H02_21 | Parameter range | 0 | 65535 | Effective way | | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| View the r model | minimum power c | consumption | resistance allowe | ed for a drive r | nodel. The val | lue cannot be | changed and depend | s only on the | drive |

| | Description | Built-in br power | ake resistance | Alter mode | Only show | factory default | Manufacturer registration | Unit | W |
|--------|--------------------|----------------------|----------------|------------------|--------------|------------------------|---------------------------|--------------|--------|
| H02_22 | Parameter range | 0 | 65535 | Effective way | | Adaptatio n pattern | P/S/T | Data type | Uint16 |

22

View the built-in brake resistance power of a certain driver model, which cannot be changed and is only related to the driver model.

| | Description | Built-in brake resistance value | | Alter mode | Only show | factory default | Manufacturer registration | Unit | Ω |
|---|--------------------|------------------------------------|-------|------------------|--------------|------------------------|------------------------------|--------------|--------|
| H02_23 | Parameter range | 0 | 65535 | Effective way | | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| View the built-in brake resistance value of a certain drive model, which cannot be changed and is only related to the drive model | | | | | | | | | |

| | Description | Heat dissip | oation of resistance | Alter mode | Enable off | factory default | Manufacturer registration | Unit | W | | |
|-------------|--|-------------|-------------------------|------------------|------------------------------|------------------------|---------------------------|--------------|--------|--|--|
| H02_24 | Parameter range | 0 | 65536 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 | | |
| setting the | setting the heat dissipation coefficient of the resistor is effective for both the internal and external brake resistors | | | | | | | | | | |

| | Description | Brake resi | stance setting | Alter mode | Enable off | factory default | 3 | Unit | W |
|--|--------------------|------------|----------------|------------------|------------------------------|------------------------|-------|--------------|--------|
| H02_25 | Parameter range | 0 | 3 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Set 0: Use built-in brake resistance; Setup 1: Use an external brake resistor; Setup 2: Use internal + external brake resistors in parallel; Setup 3: No brake resistance is used | | | | | | | | | |

| | Description | External b resistance | uilt-in brake power | Alter mode | Enable off | factory default | 1 | Unit | W |
|---|--------------------|--------------------------|------------------------|------------------|------------------------------|------------------------|-------|--------------|--------|
| H02_26 | Parameter range | 0 | 65535 | Effective way | with immediat e effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Sets the power of the external brake resistance of a certain type of driver | | | | | | | | | |

| | Description | External b resistance | uilt-in brake value | Alter mode | Enable off | factory default | 65535 | Unit | Ω |
|---|--------------------|--------------------------|------------------------|------------------|-----------------------------|-----------------------|-------|--------------|--------|
| H02_27 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set the resistance value of the external brake resistance of a certain type of driver | | | | | | | | | |

Set the resistance value of the external brake resistance of a certain type of driver

| | Description | Manufactu reservation | ırer's n | Alter mode | Enable off | factory default | 0 | Unit | - | |
|---------|--|--------------------------|-------------|------------------|-----------------------------|------------------------|-------|-----------|--------|--|
| 02_30 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptatio n pattern | P/S/T | Data type | Uint16 | |
| Manufac | Manufacturer parameters can be medified only after the permission of the manufacturer Users do not medify them | | | | | | | | | |

Manufacturer parameters can be modified only after the permission of the manufacturer. Users do not modify them.

| | Description | System par initialized | System parameters are initialized | | Enable off | factory default | 0 | Unit | - |
|--------|--------------------|---------------------------|-----------------------------------|------------------|-----------------------------|------------------------|-------|-----------|--------|
| H02_31 | Parameter range | 0 | 5 | Effective way | with immediate effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |

Set 0: no effect;

Set 1: Restore user related factory parameters.

Set 2: Clear the H0B_33 fault record.

Setup 3: Restore the factory registration parameters of the motor and drive (require the manufacturer's permission);

Set 5: Restore all system parameters. After this operation, you need to re-match the motor drive parameters, and you need to re-enter the

password to reset 3 options (with the manufacturer's permission);

Note: Normal use option 1 to restore the parameters set by the user; System parameter initialization function option 3/5, non-manufacturer technical personnel do not use;

| | Description | The panel function b | displays the y default | Alter mode | Enable off | factory default | 50 | Unit | - | |
|-----------|--|----------------------|---------------------------|------------------|-----------------------------|------------------------|-------|-----------|------------|--|
| 02_32 | Parameter range | 0 | 99 | Effective way | with immediate effect | Adaptatio n pattern | P/S/T | Data type | Uint1 6 | |
| Manufactu | Manufacturer parameters can be modified only after the permission of the manufacturer. Users do not modify them. | | | | | | | | | |

24

Depending on the Settings, the panel can automatically switch to the monitoring parameter display mode (H0B group parameters), and H02_32 is used to set the in-group bias of H0B group parameters.

| Set Value | H0BGroup | Remark |
|-----------|------------|---|
| | Parameters | |
| 0 | H0B_00 | Motor speed is not zero, panel display H0B_00(actual motor speed) |
| 3 | H0B_03 | Motor speed is not zero, panel display H0B_03(input signal DI monitoring) |

4.DI/DO parameters(H03-H04)

| | Input terminal | DI function options | | | |
|--------------------------|---|---|--|--|--|
| InFun Set vable | Symbol | Function | | | |
| 1 | SON | servo motor is enabled | | | |
| 2 | ALM_RST | Fault alarm reset | | | |
| 6 | CMD1 | Multi-segment running instruction switch 1 | | | |
| 7 | CMD2 | Multi-segment running instruction switch 2 | | | |
| 14 | P_OT | Forward overrange switch | | | |
| 15 | N_OT | Reverse overrange switch | | | |
| 18 | JOG_CMD+ | velocity is moving in a positive direction | | | |
| 19 | JOG_CMD- | velocity points in the opposite direction | | | |
| 21 | FWD-EN | Speed forward running | | | |
| 22 | REV-EN | Speed reverse operation | | | |
| 26 | SPDDirSel | Speed mode direction switch | | | |
| 28 | PosInSen | Multi - segment position running command enable | | | |
| 31 | Home_Switch | External origin switch | | | |
| 32 | Homeing_Start | Origin return was enabled. Procedure | | | |
| 34 | EmergencyStop | emergency shut down | | | |
| 35 | ClrPosErr | Error Counter | | | |
| 37 | PulseInhibit | Pulse In hibit | | | |
| 41 | Home_Record | Set current position to origin (zero bit) | | | |
| Note: InFun option (a DI | function option can only be associated wi | th one DI terminal and cannot be assigned repeatedly; otherwise, a DI | | | |

duplication assignment fault alarm ER.130 will occur)

| | Description | DI1 Tern Function | ninal Selection | Alter mode | Advanced configuration | factory default | 1 | Unit | - |
|--|--------------------|----------------------|--------------------|------------------|--------------------------|-----------------------|-------|--------------|--------|
| H03_02 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Factory default association: InFun1 servo enable; If you need to change the associated function, see Input Terminal DI Function Option Table. | | | | | | | | | |

| | Description | DI1 Term selection | inal logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|--------------------|-----------------------|------------|------------------|--------------------------|-----------------------|-------|--------------|--------|
| H03_03 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: indicates that signal conduction is effective, disconnection is invalid (positive logic input); Set 1: indicates that the signal disconnection is valid and the conduction is invalid (inverse logic input); | | | | | | | | | |

| | Description | DI2 Term | inal Function | Alter | Advanced | factory | 2 | Unit | _ |
|---|---------------------|-------------|---------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| | Description | Selection | | mode | configuration | default | 2 | Onit | _ |
| H03_04 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Factory de | efault association: | InFun2 alar | m reset; | | | | | | |
| If you need to change the associated function, see Input Terminal DI Function Option Table. | | | | | | | | | |

| - | Description | DI2 Termir selection | al logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|-------------|--------------------|----------------------|-------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H03_05 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set 0: indi | cates that signal | conduction is | s effective, disc | connection is in | nvalid (positive log | gic input); | | | |

Set 1: indicates that the signal disconnection is valid and the conduction is invalid (inverse logic input);

| | Description | DI3 Termir Selection | al Function | Alter mode | Advanced configuration | factory default | 34 | Unit | - |
|---|--------------------|-------------------------|------------------|------------------|-----------------------------|------------------------|-------|-----------|--------|
| H03_06 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| Factory de | efault association | : InFun34 en | nergency shutdow | n; | | | | | |
| If you need to change the associated function, see Input Terminal DI Function Option Table. | | | | | | | | | |

If you need to change the associated function, see Input Terminal DI Function Option Table.

| | Description | DI3 Termin | nal logic | Alter | Advanced | factory | 0 | Unit | |
|--|--------------------|---------------|---------------------|------------------|-----------------------------|---------------------------|-------|-----------|--------|
| | Description | selection | | mode | configuration | default | 0 | Unit | - |
| H03_07 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptat ion pattern | P/S/T | Data type | Uint16 |
| Set 0: indi | icates that signal | conduction is | s effective, discon | nection is inva | alid (positive logi | c input); | | | |
| Set 1: indicates that the signal disconnection is valid and the conduction is invalid (inverse logic input); | | | | | | | | | |

| | Description | DI4 Termi | inal Function | Alter | Advanced | factory | 18 | Unit | |
|---|---------------------|------------|------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| | Description | Selection | | mode | configuration | default | 10 | Unit | - |
| H03_08 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Factory de | efault association: | InFun18 sp | eed forward dot; | | | | | | |
| If you need to change the associated function, see Input Terminal DI Function Option Table. | | | | | | | | | |

DI4 Terminal logic Alter Advanced factory 0 Description Unit _ selection mode configuration default Adaptation H03_09 with Parameter Effective pattern Data 0 1 immediate P/S/T Uint16 range way type effect Set 0: indicates that signal conduction is effective, disconnection is invalid (positive logic input);

Set 1: indicates that the signal disconnection is valid and the conduction is invalid (inverse logic input);

| | Description | DI5 Termin Selection | al Function | Alter mode | Advanced configuration | factory default | 19 | Unit | - |
|------------|--------------------|-------------------------|-------------------|------------------|-----------------------------|---------------------------|-------|-----------|--------|
| H03_10 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptati on pattern | P/S/T | Data type | Uint16 |
| Factory de | efault association | : InFun19 sp | eed negative dot; | | | | | | |

If you need to change the associated function, see Input Terminal DI Function Option Table.

| | Description | DI5 Termi selection | nal logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|---------------------|------------------------|---------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H03_11 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: indi | cates that signal c | conduction is | s effective, discon | nection is inva | alid (positive log | ic input); | | | |
| Set 1: indicates that the signal disconnection is valid and the conduction is invalid (inverse logic input); | | | | | | | | | |

| | Description | DI8 termin | nal function | Alter | Advanced | factory | 0 | Unit | - |
|--------|--------------------|------------|--------------|-----------|-----------------------------|-----------------------|-------|-----------|--------|
| H03_16 | Parameter range | 0 | 41 | Effective | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |

To change the association function, see Input Terminal DI Function Option Table.

| | Description | DI8 Termi selection | nal logical | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|---------------------|------------------------|-------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H03_17 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: indi | cates that the sign | nal is valid fo | or conduction and | invalid for di | sconnection (pos | itive logic input | t); | | |
| Set 1: indicates that the signal is disconnected and valid, and the conduction is invalid (inverse logic input); | | | | | | | | | |

| | Description | DI9 termin | nal function | Alter | Advanced | factory | 0 | Unit | |
|------------|--------------------|---------------|---------------------|------------------|-----------------------------|------------------------|-------|-----------|--------|
| | Description | Select | | mode | configuration | default | 0 | Unit | - |
| H03_18 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |
| If you nee | d to change the as | ssociation fu | nction, refer to th | e Input Termin | nal DI Function C | ptions Table. | | | |

| | Description | DI9 Termi selection | nal logical | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|-------------|---------------------|------------------------|-------------------|------------------|-----------------------------|-----------------------|-------|--------------|--------|
| H03_19 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: indi | cates that the sigr | nal is valid fo | or conduction and | invalid for di | sconnection (pos | itive logic input |); | | |

Set 1: indicates that the signal is disconnected and valid, and the conduction is invalid (inverse logic input);

| | Description | AI1 is offs | et or duty cycle | Alter | Advanced | factory | 0 | Unit | mv/pwm% |
|----------|--------------------|-------------|------------------|------------------|-----------------------------|-----------------------|-------------|---------------|-------------|
| | | is offset | - | mode | configuration | default | | | |
| H03_50 | Parameter range | -5000 | 5000 | Effective way | with immediate effect | Adaptation pattern | S/T | Data type | Uint16 |
| When the | instruction comes | from AI, th | e amount of zero | bias compensa | ation for the analo | og input. When | the externa | al analog vol | ltage input |

device cannot be adjusted to absolute 0V, this parameter can be used for input voltage bias.

When the instruction is derived from PWM, the PWM duty cycle is offset.

| | Description | AI1/PWM time const | input filtering | Alter mode | Advanced configuration | factory default | 2000 | Unit | 0.01ms |
|--------|--------------------|-----------------------|-----------------|------------------|-----------------------------|-----------------------|------|-----------|--------|
| H03_51 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S/T | Data type | Uint16 |

Low-pass filter for analog input and PWM input signal;

The larger the setting value, the faster the input response speed and the greater the influence of signal noise; The smaller the setting value, the slower the response and the smaller the impact of signal noise.

| | Description AI1 Dead zone | | Alter mode | Advanced configuration | factory default | 2000 | Unit | 0.1mV | |
|--|---------------------------|---|---------------|------------------------|-----------------------------|-----------------------|------|--------------|--------|
| H03_53 | Parameter range | 0 | 10000 | Effective way | with immediate effect | Adaptation pattern | S/T | Data type | Uint16 |
| The analog command is invalid when the analog input voltage is in the uncontrolled range. In the application scenario with serious interference, the dead zone range can be enlarged to reduce interference and avoid flapping. | | | | | | | | | |

| | Description | AI1 Zero o | lrift | Alter mode | Advanced configuration | factory default | 0 | Unit | 0.1mV |
|--|--------------------|------------|-------|------------------|-----------------------------|-----------------------|-----|-----------|--------|
| H03_54 | Parameter range | -5000 | 5000 | Effective way | with immediate effect | Adaptation pattern | S/T | Data type | Uint16 |
| The amount of zero bias compensation for the analog input. | | | | | | | | | |

| | Description | Analog va 10V/PWM to the spee | lue 1% corresponds ed value | Alter mode | Advanced configuration | factory default | 3000 | Unit | rpm | |
|----------|--|-------------------------------------|-----------------------------------|------------------|-----------------------------|-----------------------|------|--------------|--------|--|
| H03_80 | Parameter range | 0 | 6000 | Effective way | with immediate effect | Adaptation pattern | S/T | Data type | Uint16 | |
| When the | When the instruction comes from the analog quantity set the proportional relationship between the analog speed input voltage 10V and the | | | | | | | | | |

When the instruction comes from the analog quantity, set the proportional relationship between the analog speed input voltage 10V and the motor speed; If 3000 is set, the speed of the 10V motor is 3000r/min.

When the instruction comes from PWM, set the PWM duty cycle to 100% and the proportional relationship between the motor speed; If the duty cycle is set to 3000, the motor speed is 3000r/min when the duty cycle is 100%.

| | Description | The analog correspond value | g quantity 10V ds to the torque | Alter mode | Advanced configuration | factory default | 100 | Unit | 0.01 times |
|--|--------------------|-----------------------------------|------------------------------------|------------------|-----------------------------|-----------------------|-----|-----------|------------|
| H03_81 | Parameter range | 0 | 6000 | Effective way | with immediate effect | Adaptation pattern | S/T | Data type | Uint16 |
| Set the proportional relationship between analog torque input voltage and motor torque; Setting 100 indicates that the torque of the 10V | | | | | | | | | |
| voltage motor is 100% of the rated torque. | | | | | | | | | |

| | Output terminal DO function option table | | | | | | | | |
|----------------------------------|--|--|--|--|--|--|--|--|--|
| OutFun Set Value Symbol Function | | | | | | | | | |
| | | | | | | | | | |

29

| 1 | S_RDY | S_RDY |
|----|----------------|---|
| 5 | COIN | Positioning complete output |
| 9 | BRK | Brake output control |
| 11 | ALM | Error alarm OUT |
| 16 | Home_Attaion | origin returns to zero to complete the output |
| 17 | ElecHomeAttain | Electrical return to zero completes output |
| 18 | ToqReach | Torque to the output |
| 19 | V-Arr | Speed to the output |
| 24 | BldcPulsout | Pulse Output |

| - | Description | DO1 Terminal Function | | Alter | Advanced | factory | 1 | Unit | |
|---|--------------------|-----------------------|----|------------------|--------------------------|-----------------------|-----------|--------------|--------|
| | Description | Selection | | mode | configuration | default | 1 | Oint | |
| H04_00 | Parameter range | 0 | 24 | Effective way | with immediate effect | Adaptation pattern | P/S/ T | Data type | Uint16 |
| Factory default association: OnFun1 servo is ready; | | | | | | | | | |

If you need to change the associated function, see the Output Terminal DO Function Option Table.

| H04_01 | Description | DO1 Term selection | inal logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|--------------------|-----------------------|------------|------------------|--------------------------|-----------------------|-----------|--------------|--------|
| | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/ T | Data type | Uint16 |
| Set 0: when the signal is valid, the optocoupler is on (positive logic output); | | | | | | | | | |
| Set 1: when the signal is effective, the optocoupler is turned off (inverse logic output); | | | | | | | | | |

| | Description | DO2 Termi Selection | nal Function | Alter mode | Advanced configuratio n | factory default | 11 | Unit | - |
|--|--------------------|------------------------|--------------|------------------|-------------------------------|-----------------------|-------|-----------|--------|
| H04_02 | Parameter range | 0 | 24 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Factory default association: OnFun11 fault alarm output; If you need to change the associated function, see the Output Terminal DO Function Option Table. | | | | | | | | | |

| | Description | DO2 Term selection | inal logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|---------------------|--------------------|--------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H04_03 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: whe | en the signal is va | lid, the opto | coupler is on (pos | itive logic out | put); | | | | |
| Set 1: when the signal is effective, the optocoupler is turned off (inverse logic output); | | | | | | | | | |
| | | | | (| 30] | | | | |

| Description | | DO3 Termi Selection | nal Function | Alter mode | Advanced configuration | factory default | 5 | Unit | - |
|---|--------------------|------------------------|--------------|------------------|--------------------------|-----------------------|-------|--------------|--------|
| H04_04 | Parameter range | 0 | 24 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Factory default association: OnFun5 positioning completed output; If you need to change the associated function, see the Output Terminal DO Function Option Table. | | | | | | | | | |

| | Description | DO3 Term selection | inal logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|--------------------|-----------------------|------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H04_05 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: when the signal is valid, the optocoupler is on (positive logic output); | | | | | | | | | |
| Set 1: when the signal is effective, the optocoupler is turned off (inverse logic output); | | | | | | | | | |

| | Description | DO4 Term Selection | inal Function | Alter mode | Advanced configuration | factory default | 18 | Unit | - |
|--|--------------------|-----------------------|---------------|------------------|-----------------------------|-----------------------|-------|--------------|--------|
| H04_06 | Parameter range | 0 | 24 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Factory default association: OnFun18 torque reaches output; | | | | | | | | | |
| If you need to change the associated function, see the Output Terminal DO Function Option Table. | | | | | | | | | |

| | Description | DO4 Term selection | inal logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|--------------------|-----------------------|------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H04_07 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: when the signal is valid, the optocoupler is on (positive logic output); | | | | | | | | | |
| Set 1: when the signal is effective, the optocoupler is turned off (inverse logic output); | | | | | | | | | |

| | Description | DO5 Terminal Function | | Alter | Advanced | factory | 19 | Unit | _ |
|---|--|-----------------------|----|------------------|-----------------------------|-----------------------|-------|--------------|--------|
| | Decemption | Selection | | mode | configuration | default | 17 | Oint | _ |
| H04_08 | Parameter range | 0 | 24 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Factory default association: OnFun19 speed to output; | | | | | | | | | |
| If you nee | If you need to change the associated function, see the Output Terminal DO Function Option Table. | | | | | | | | |

| | Description | DO5 Terr selection | ninal logic | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--|--------------------|-----------------------|-------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H04_09 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set 0: when the signal is valid, the optocoupler is on (positive logic output); | | | | | | | | | |
| Set 1: when the signal is effective, the optocoupler is turned off (inverse logic output); | | | | | | | | | |

4.1.4-Position control parameter(H05)

| | Description | Source of p command | position | Alter mode | Enable off | factory default | 0 | Unit | - |
|--------|--------------------|------------------------|----------|------------------|------------------------------|------------------------|---|-----------|--------|
| H05_00 | Parameter range | 0 | 2 | Effective way | with immediat e effect | Adaptatio n pattern | Р | Data type | Uint16 |

When H02_00=1(position control mode);

Set 0: pulse command (the external controller outputs high-speed pulse train, and the motor positioning and rotation are controlled by pulse input to the motor drive, and the input pulse form is set by H05-15)

Set 1: multi-segment position instruction (set by internal multi-segment position parameter to control motor rotation, refer to Section 3.8 / Group H11 internal multi-segment position for details)

| 1105 04 | Description | Position command low-pass filtering time constant | | Alter mode | Enable off | factory default | 0 | Unit | ms |
|---------|--------------------|---|-------|------------------|-----------------------------|-----------------------|---|-----------|--------|
| H05_04 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |

Set the first-order low-pass filter time constant of the position command;

Setting this parameter will increase the delay of positioning response but has no effect on the displacement (total number of position instructions).

When the external controller does not set the function of pulse acceleration and deceleration, and the motor impact is relatively large, the value of this parameter can be appropriately increased to indirectly achieve the passive hysteresis effect;

| | Description | Electron (numera | ic gear ratio 1 tor) | Alter mode | Advanced configuration | factory default | 131072 | Unit | - |
|--------|--------------------|---------------------|-------------------------|------------------|--------------------------|-----------------------|--------|--------------|------------|
| H05_07 | Parameter range | 0 | 1073741824 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint 32 |

Set the position command electronic gear ratio molecule, AIMotor motor encoder resolution is 131072; L When the electronic gear ratio molecule is fixed as the motor resolution, the electronic gear ratio (H05-09) parameter value is the number of pulse commands required for the motor to rotate 1 turn; L When the electronic gear ratio molecule is not fixed as the motor resolution, the calculation method of the motor gear ratio is as follows:

Example 1: It is known that the motor drives the lead screw through the coupling to move in a straight line. The screw pitch is 10mm, and it is required that 1 pulse unit corresponds to 0.01mm.

Calculate :

Eg2: It is known that the motor drives the pulley through the coupling to move in a straight line. The circumference of the pulley is 60mm, and 5 pulse units are required to correspond to 0.02mm.

| $\frac{B}{A} = \frac{131072}{5} \times \frac{0.02}{60}$ | $\frac{B}{A} = \frac{131072}{15000}$ | Electronic gear molecule=131072 | Denominator=15000 |
|---|--------------------------------------|---------------------------------|-------------------|
| $\frac{B}{A} = \frac{131072}{1} \times \frac{0.01}{10}$ | $\frac{B}{A} = \frac{131072}{1000}$ | Electronic gear molecule=131072 | Denominator=1000 |

| | Description | Electronic (numerato | gear ratio 1 r) | Alter mode | Advanced configuration | factory default | 1000 | Unit | - |
|--|--------------------|-------------------------|---------------------|------------------|-----------------------------|-----------------------|-----------|--------------|----------------|
| H05_09 | Parameter range | 0 | 1073741824 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint32 |
| Set the pos | sition command el | lectronic gea | ar score, the facto | ry default is 1 | 000, indicating the | at the motor need | ds 1000 p | oulse comma | nd input for 1 |
| turn; L When the electronic gear ratio molecule (H05-07) is fixed as the motor resolution, the value of the electronic gear ratio parent | | | | | | | | | |
| parameter is the number of pulse commands required for the motor to rotate 1 turn; | | | | | | | | | |

| | Description | Pulse com | mand pattern | Alter mode | Enable off | factory default | 0 | Unit | - |
|--------|--------------------|-----------|--------------|------------------|--------------------------|-----------------------|---|-----------|--------|
| H05_15 | Parameter range | 0 | 3 | Effective way | power off and restart | Adaptation pattern | Р | Data type | Uint16 |

Set 0: pulse + direction positive logic (high-speed pulse train controls motor rotation, direction signal OFF is CW direction, direction signal ON is CCW direction);

Set 1: pulse + direction negative logic (high-speed pulse train controls motor rotation, direction signal OFF is CCW direction, direction signal ON is CW direction);

Set 2: A/B phase orthogonal pulse 4 times frequency (A phase before B phase 90° motor positive turn, B phase before A phase 90° motor reverse);

Set 3: CW/CCW double pulses (CCW pulse receives CW pulse to disconnect the motor forward, CW pulse receives CCW pulse to disconnect the motor reverse);

| | Description | Electronic gear ratio 1 | | Alter | Advanced | factory | 1 | Unit | _ | |
|--|--|-------------------------|---|------------------|--------------------------|-----------------------|---|-----------|--------|--|
| | Description | (numerator) | | mode | configuration default | | 1 | Ollit | - | |
| H05_19 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint32 | |
| Set the position command electronic gear score, the factory default is 1000, indicating that the motor needs 1000 pulse command input for 1 turn; L When the electronic gear ratio molecule (H05-07) is fixed as the motor resolution, the value of the electronic gear ratio parent | | | | | | | | | | |
| parameter | parameter is the number of pulse commands required for the motor to rotate 1 turn; | | | | | | | | | |

| | Description | The locating completion | | Alter | Advanced | factory | 02 | Unit | Encoder | | |
|---|--------------------------------------|-------------------------|--------------------|------------------|-----------------------------|-----------------------|----|-----------|---------|--|--|
| | | threshold | | mode | configuration | default | 92 | | unit | | |
| H05_21 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 | | |
| Set the positioning completion threshold, motor position deviation value < positioning completion threshold, OutFun5 (COIN) positioning | | | | | | | | | | | |
| completio | completion signal COIN is effective; | | | | | | | | | | |
| The positi | oning completion | n signal COR | N is only valid in | position mode | and motor enable | d state: | | | | | |

| | Description | Description Origin return enable control | | Alter mode | Advanced configuration | factory default | 0 | Unit | - | | |
|---|---|--|---|---|--|--|-------------------|-----------|--------|--|--|
| H05_30 | Parameter range | 0 | 8 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 | | |
| Set the origin return mode and trigger signal source; | | | | | | | | | | | |
| Set Value | | Trigge | er signal | | Zero return mode | | Remark | | | | |
| 0 | Close the origin | and return | | | - | | | - | | | |
| 1 | Enable homing t | hrough DI (| (Homeing_Start) | Origin research | | When the motor is enabled, the signal is effective | | | | | |
| 2 | Enable electrical | l home throu | ugh DI (Homeing | Electric back to zero | | When the motor is enabled, the signal is effective | | | | | |
| 3 | After the function returns to the original | on is enabled | Origin research After the device is powered again, the first enable signate offective effective | | | s powered on able signal is ve | | | | | |
| 4 | Communication return | control (H0 | 05_30 write 4) ena | Origin r | After the motor is enabled, the command takes effect | | | | | | |
| 5 | Communication electrical return | control (H0 to zero | 05_30 write 5) Ena | Electric back to zero | | After the motor is enabled, the command takes effect | | | | | |
| 6 | Communication current position | control (H0 | 05_30 write 6) trig igin | Set position H0B-07 to 0 | | After the trigger succeeds, H05_30=0 | | | | | |
| 8 | Trigger the curre (HomeRecord) | ent position | as the origin throu | Set position H0B-07 to 0 After the trigger succeeds H05_30=0 H05_30=0 | | | r succeeds, =0 | | | | |
| Note 1: For | Note 1: For communication control (H05_30 writes 4/H05_30 writes 5/H05_30 writes 6), H05_30 automatically sets to 0 after the command | | | | | | | | | | |

(34)

| | Description | Zero return n | node | Alter mode Enable OFF factory default 0 Unit | | | | | | |
|------------|-----------------------|---------------------|---------------------|--|--------------------------|-----------------------|---------|-------------------|----------------|--|
| H05_31 | Parameter range | 0 | 16 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 | |
| Set the mo | otor initial directio | n, deceleration | point, and ori | gin during ori | gin search | | | | | |
| Set | Search | deceleratio | Original | | | Process steps | | | | |
| value | direction | n point | point | | | Tiocess steps | | | | |
| 0 | Forwarder | Origin | Origin | Motor first s | searches for the ori | gin switch at a hi | gh sp | eed in the set of | direction. | |
| 0 | 1 of warder | Switch | Switch | When it enc | ounters the rising e | edge of the origin | swite | ch signal, it sta | rts to run and | |
| 1 | Reverse | Origin Switch | Origin Switch | detangle at a low speed. When it detashes from the falling edge of the origin switch signal, the motor reverses and continues to search for the rising edge of the origin switch signal at a low speed. | | | | | | |
| | F 1 | Origin | Motor Z | Motor first searches phase Z at a high speed in the set direction. When | | | | | | |
| 2 | Forwarder | Switch | signal | encounterin | g the rising edge of | f the motor Z trus | st sign | al, it starts to | reverse to run | |
| 2 | D | Origin | Motor Z | at a low spe | ed. When encounte | ering the rising ed | lge of | the other side | of phase Z, | |
| 3 | Reverse | Switch | signal | the signal st | ops immediately a | nd returns to zero | succe | essfully. | | |
| | | Origin | Motor Z | Motor first s | searches for the ori | gin switch at a hi | gh sp | eed in the set of | direction. | |
| 4 | Forwarder | Switch | signal | When it encounters the rising edge of the origin switch signal, it starts to reverse | | | | | | |
| 5 | Reverse | Origin Switch | Motor Z signal | and detangle at a low speed. When it detashes from the falling edge of the origin switch signal, it reverses again and searches for the rising edge of the origin switch signal at a low speed. | | | | | | |
| 6 | Forwarder | Positive | Positive | Motor first searches for the origin switch at a high speed in the set direction. | | | | | | |
| 0 | rorwarder | distance | distance | When it enc | ounters the rising e | edge of the forwa | rd ove | errange switch | signal, it | |
| 7 | Reverse | Inverse distance | Inverse distance | starts to reverse and detangle at a low speed. When it detashes from the falling edge of the forward overrange switch signal, the motor reverses again at a low speed and searches for the rising edge of the forward overrange switch signal. | | | | | | |

| | | | | · · · · · · · · · · · · · · · · · · · |
|----|-----------|------------------------------------|------------------------------------|--|
| 8 | Forwarder | Positive | Motor Z | Motor first searches for the forward overrange switch at a high speed in the set |
| | | distance | signal | direction. When it meets the rising edge of the forward overrange switch signal, |
| 9 | Reverse | Inverse distance | Motor Z signal | it starts to decelerate and reverse to run away from it. When it detashes from the falling edge of the forward overrange switch signal, it continues to run until the motor Z trust signal stops immediately and returns to zero successfully. |
| 10 | Forwarder | Mechanical limiting position | Mechanical limiting position | Motor first searches for the mechanical limit position at low speed with the set direction and torque (torque set by H05_56). When the mechanical limit position reaches the blocked rotation and the torque reaches the upper limit of the torque |
| 11 | Reverse | Mechanical limiting position | Mechanical limiting position | limit of touch stop and return to zero, the motor stops immediately and returns to zero successfully while keeping the default time. |
| 12 | Forwarder | Mechanical limiting position | Motor Z signal | Motor first searches for the mechanical limit position with the set direction and torque (torque set by H05_56) at a low speed. When the mechanical limit position reaches the blocked rotation and the torque reaches the upper limit of the |
| 13 | Reverse | Mechanical | Motor Z | zero torque limit and keeps the default time, the motor runs in reverse until the |

(35 **)**

| | | | limiting | signal | motor Z trust signal stops immediately and returns to zero successfully. |
|--|----|-----------|------------|----------------|---|
| | | | position | | |
| | 14 | Forwarder | | | Motor returns to the zero position in a single turn predetermined by the user in |
| | | Reverse | Flectrical | raturn to zaro | the set direction at a high speed, ignoring the data of the number of turns. Clears |
| | 15 | | operation. | | the current position upon arrival. |
| | 16 | Auto | | | Motor returns to the zero position in a single turn predetermined by the user at a |
| | | | | | high speed in the optimal direction. |

Note 1: Please associate the DI function options corresponding to the deceleration point, origin switch and positive and negative overrange switch that are useful in the selected mode, otherwise an alarm will occur, ER.601 return to zero failure;

Note 2: In the selected mode, if the deceleration point is the origin switch and the positive and negative overrange switch DI is associated,

the motor encounters the overrange switch in the search path and the motor automatically reverses to continue the search;

Note 3: In the process steps, the high-speed search speed is set by the H05_32 parameter, and the low-speed search speed is set by the H05_33 parameter.

Note 4: If the origin is not found within the H05_35 parameter time, the alarm ER.601 return to zero timeout will occur;

Note 5: After the origin resetting is successful, the DO function (OutFun16-HomeAttain) takes effect when the output of the origin resetting to zero is completed, while the output of the origin resetting to zero is invalid when OFF is enabled.

Note 6: Return to origin function is effective in position mode; When currently running in position mode internal multi-bit control, you need to disable the multi-bit enable signal first.

| H05_32 | Description | High speed switch sign | search origin al speed | Alter mode | Advanced configuration | factory default | 100 | Unit | rpm |
|--------|--------------------|---------------------------|---------------------------|------------------|-----------------------------|-----------------------|-----|--------------|--------|
| | Parameter range | 0 | 3000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |
| . ~ . | | | | | | | | | |

1: Set the setting of high-speed search speed in the origin return process; 2: Speed setting for starting electrical return to zero;

| H05_33 | Description | Low spee switch sig | ed search origin gnal speed | Alter mode | Advanced configuration | factory default | 100 | Unit | rpm |
|--------|--------------------|------------------------|--------------------------------|------------------|-----------------------------|-----------------------|-----|--------------|--------|
| | Parameter range | 0 100 | | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

Set the low search speed setting in the origin return process; The lower the setting value is, the higher the origin search accuracy is. If the selected reduction point of the origin return mode is the machine limit position (block turn back to zero), the motor will always run at low speed until the origin return is successful;

| | Description | The accele decelerations searching | eration and on times when the origin | Alter mode | Enable OFF | factory default | 200 | Unit | ms | | |
|---|--|--|--|------------------|-----------------------------|-----------------------|-----|-----------|--------|--|--|
| H05_34 | Parameter range | 0 | 200 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 | | |
| When setting the origin resetting mode, the speed change time of the motor from 0-1000rpm can be appropriately increased when the | | | | | | | | | | | |
| impact of | impact of the origin resetting motor is large. | | | | | | | | | | |

36
| | Description | Origin search timeout | | Alter mode | Enable OFF | factory default | 60000 | Unit | ms |
|---|--------------------|-----------------------|-------|------------------|-----------------------------|-----------------------|-------|--------------|--------|
| H05_35 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |
| When setting the origin resetting mode, the speed change time of the motor from 0-1000rpm can be appropriately increased when the | | | | | | | | | |

impact of the origin resetting motor is large.

| | Description | Mechanical origin offset | | Alter | Enable | factory default | 0 | Unit | command |
|--------|--------------------|--------------------------|-----------|------------------|-----------------------------|-----------------------|---|-----------|---------|
| | Description | | | mode | OFF | lactory default | 0 | Oint | unit |
| H05_36 | Parameter range | -999999999 | 999999999 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Int32 |

Set the offset position after the origin is restored, and continue to perform the offset position action after the origin is restored successfully. If the offset of the origin of H05_36 is 0, the electrical zero position is consistent with the origin position, and the absolute position of the current motor H0B_07 will automatically clear to 0 after the origin is successfully returned to zero. Return to electrical zero position You go back to your original position;

If the origin offset of H05_36 \neq 0, the electrical zero is equal to the origin offset position. After the origin returns to zero successfully,

continue to go to the offset position and then stop, the absolute position of the current motor

H0B_07 is the offset position of the origin, and returning to zero is returning to the offset position of the origin;

If the origin resetting mode $H05_{31}=14/15/16$, when the single-turn electrical zero, the motor returns to the position in the single turn, and the mechanical origin offset is invalid.

If the origin resetting mode H05-31=6/7/10/11, H05-36 sets the mechanical origin offset (positive = positive direction; Negative = negative direction), when the offset value returns to the origin square

ER.668 will be alerted when it is consistent, the motor does not perform action.

| | Description | Touch stop torque limi | return to zero t | Alter mode | Advanced configuration | factory default | 1000 | Unit | 0.10% |
|--------|--------------------|---------------------------|---------------------|------------------|--------------------------|-----------------------|------|--------------|--------|
| H05_58 | Parameter range | 0 | 3000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

Set the origin return mode ($H05_{31}=10/11/12/13$) the maximum positive and negative torque limit in the process of stopping and returning to zero; Must ensure that the set torque can drive the load movement;

4.1.5 Speed Control Parameters (H06)

| | Description | Main speed instruction A source | | Alter mode | Enable OFF | factory default | 0 | Unit | - |
|--------|-----------------|------------------------------------|---|------------------|-----------------------------|-----------------------|---|-----------|--------|
| H06_00 | Parameter range | 0 | 2 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |

| | Description | Secondary speed instruction B source | | Alter mode | Enable OFF | factory default | 5 | Unit | - |
|--------|-----------------|--------------------------------------|---|------------------|-----------------------------|-----------------------|---|-----------|--------|
| H06_01 | Parameter range | 0 | 5 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |

Set 0: from the given value of H06_03; Let 1: The voltage from external AI1 analog is given; Set 5: From the internal multi-speed given

| | Description | Speed co selection | ommand | Alter mode | Enable OFF | factory default | 0 | Unit | - |
|---|-----------------|-----------------------|--------|------------------|-----------------------------|-----------------------|---|-----------|--------|
| H06_02 | Parameter range | 0 | 4 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |
| When H02_00=0 speed control mode; Set 0: Select the main speed instruction A source to run; Set 1: Select the auxiliary speed instruction | | | | | | | | | |

| | Description | Speed con communic value | nmand cation setting | Alter mode | Advanced configuration | factory default | 200 | Unit | rpm |
|--|--------------------|--------------------------------|-------------------------|------------------|--------------------------|-----------------------|-----|-----------|-------|
| H06_03 | Parameter range | -6000 | 6000 | Effective way | with immediate effect | Adaptation pattern | S | Data type | Int16 |
| When H06 02=0, the motor running speed is set by this parameter; | | | | | | | | | |

| | Description | JOG jog s value | peed setting | Alter mode | Advanced configuration | factory default | 100 | Unit | rpm |
|--------|--------------------|--------------------|--------------|------------------|--------------------------|-----------------------|-----|-----------|--------|
| H06_04 | Parameter range | 0 | 6000 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |

When the DI function of H03 group is InFun18 (JOG_CMD+) and InFun19 (JOG_CMD-), this parameter is used to set the JOG running speed of the motor.

| | Description | Speed cor acceleration constant | nmand on ramp time | Alter mode | Advanced configuration | factory default | 0 | Unit | ms |
|---|--------------------|---------------------------------------|-----------------------|------------------|--------------------------|-----------------------|---|-----------|--------|
| H06_05 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |
| In the setting speed mode, the acceleration time of the motor is determined by 0-1000rpm (the acceleration and deceleration time of the | | | | | | | | | |

38

internal multi-speed is determined by the H12 group parameters, which has nothing to do with it);

| | Description Speed command deceleration ramp time constant | | Alter mode | Advanced configuration | factory default | 0 | Unit | ms | |
|--|---|---|---------------|------------------------|-----------------------------|-----------------------|------|-----------|--------|
| H06_06 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |
| Deceleration time of motor from 1000-0rpm in setting speed mode; The acceleration and deceleration time of multiple velocities in the speed mode is determined by H12 group parameters, and has nothing to do with this parameter. | | | | | | | | | |

| H06_18 | Description | Speed rea threshold | ches signal | Alter mode | Advanced configuration | factory default | 1000 | Unit | rpm |
|---|--------------------|------------------------|-------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| | Parameter range | 10 | 6000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set the speed condition for the speed to arrive; | | | | | | | | | |
| When the actual motor speed after filtering is >= the set value, the speed is judged to arrive, and the OutFun19 (V-ARR) speed arrival signal | | | | | | | | | |
| is effective. Otherwise, the speed arrival signal is invalid; | | | | | | | | | |

4.1.6 Torque control parameters (H07)

| | Description | Main torc source | ue instruction A | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--------|--------------------|---------------------|------------------|------------------|-----------------------------|-----------------------|---|-----------|-------|
| H07_00 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | Т | Data type | Int16 |

Set 0: the main torque instruction is derived from the H07_03 digital given; Set 1: The main torque instruction comes from the external AI1 analog voltage given;

| | Description | Auxiliary instructio | torque n B source | Alter mode | Advanced configuration | factory default | 1 | Unit | - |
|--------|--------------------|-------------------------|----------------------|------------------|-----------------------------|-----------------------|---|-----------|-------|
| H07_01 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | Т | Data type | Int16 |

Set 0: the main torque instruction is derived from the H07_03 digital given; Set 1: The main torque instruction comes from the external AI1 analog voltage given;

| | Description | Torque in | struction | Alter | Advanced | factory | 0 | Unit | |
|---------|-------------|-----------|-----------|-----------|---------------|------------|---|-----------|-------|
| 1107 02 | Description | selection | | mode | configuration | default | 0 | Ullit | - |
| H07_02 | Parameter | 0 | 1 | Effective | with | Adaptation | т | Data tuna | Int16 |
| | range | 0 | | way | immediate | pattern | 1 | Data type | mtro |

l

| | | effect | | |
|--|--|--------|--|--|
| | | | | |

When H02_00=2(torque control mode); Set 0: Select the main torque instruction A source to run; Set 1: Select the auxiliary torque instruction B source to run;

| | Description | Torque co communi value | ommand cation setting | Alter mode | Advanced configuration | factory default | 0 | Unit | 0.10% |
|--------|--------------------|-------------------------------|-----------------------|------------------|-----------------------------|------------------------|---|-----------|-------|
| H07_03 | Parameter range | -3000 | 3000 | Effective way | with immediate effect | Adaptatio n pattern | Т | Data type | Int16 |

When H02_00=2(torque control mode); Set the torque limit of the positive and negative direction output when the motor is running, and limit the torque output is equal to limit the current output;

100.0%= 1 times of motor torque (1 times of motor torque = motor rated torque and motor rated current);

This parameter, together with H07_09/H07_10 and manufacturer's parameter H00_43/H01_03, is used as the actual maximum current output limit of the motor, and its low effective value is taken.

| | Description | Torque co time const | mmand filter | Alter mode | Advanced configurat ion | factory default | 79 | Unit | 0.01ms |
|------------|-----------------------|-------------------------|---------------------------------|------------------|-------------------------------|-----------------------|-----------|-----------------|-------------|
| H07_05 | Parameter range | 0 | 3000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| By setting | the low-pass filte | ring time of | the torque comm | and, the opera | tion of the tor | rque command car | n be smoo | ther and the vi | bration can |
| be reduced | 1. If the setting val | lue is too la | rge, the motor res _l | ponsiveness w | vill decrease. | | | | |

| | Description | Positive | internal torque | Alter | Advanced | factory | 3000 | Unit | 0.10% |
|--------|-----------------|----------|-----------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| | | 1111111 | | moue | configuration | uciaun | | | |
| H07_09 | Parameter range | 0 | 4000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |

Set the torque limit of the output in the positive direction when the motor is running, any mode is valid;

100.0%= 1 times motor torque (1 times motor torque = rated motor torque and rated motor current);

Limited torque output = limited current output, this parameter and the manufacturer's parameter $H00_{43}/H01_{03}$ are used as the actual maximum current output limit of the motor, the lower effective;

| | Description | Negative limit | e internal torque | Alter mode | Advanced configuration | factory default | 3000 | Unit | 0.10% |
|--------|-----------------|-------------------|-------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H07_10 | Parameter range | 0 | 4000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |

Set the torque limit of the negative direction output when the motor is running, independent of the mode; Limiting torque output is equal to limiting current output;

100.0%= 1 times of motor torque (1 times of motor torque = motor rated torque and motor rated current);

Limit torque output = limit current output. This parameter and the manufacturer's parameter $H00_{43}/H01_{03}$ are both used as the actual maximum current output limit of the motor, and the low effective value is taken.

| | Description | Torque c speed lin | ontrol forward nit value | Alter mode | Advanced configuration | factory default | 3000 | Unit | rpm |
|------------|---------------------|-----------------------|-----------------------------|------------------|-----------------------------|-----------------------|------------|----------------|-----------------|
| H07_19 | Parameter range | 0 | 6000 | Effective way | with immediate effect | Adaptation pattern | Т | Data type | UInt16 |
| When sett | ing the torque mode | e, the maxi | mum forward spe | ed limit of the | e motor should be | limited. When s | setting th | ne torque cont | rol, the speed |
| limit must | be set to avoid exc | essive spee | ed caused by the u | unlimited spee | d increase of the | light load motor | | | |
| The torau | e outnut nercentage | and sneed | limit are set. Wh | en the load is | less than the tora | ie output the m | otor will | accelerate an | d rotate in the |

The torque output percentage and speed limit are set. When the load is less than the torque output, the motor will accelerate and rotate in the direction of the torque output. When the load is accelerated to the speed limit or the output torque is insufficient to support continued acceleration, the motor will stop accelerating, and the speed will fluctuate according to the load fluctuation. When the load is about equal to the torque output, the motor will stop. When the load is greater than the output torque, the motor will be dragged to reverse rotate into reverse damping torque;

| | Description | Negative s | peed limit value | Alter | Advanced | factory | 2000 | Unit | ram |
|------------|--------------------|----------------|------------------|------------------|-----------------------------|-----------------------|----------|-----------------|---------------|
| | Description | for torque | control | mode | configuration | default | 3000 | Unit | Ipili |
| H07_20 | Parameter range | 0 | 6000 | Effective way | with immediate effect | Adaptation pattern | Т | Data type | UInt16 |
| When setti | ing the torque mo | ode, limit the | reverse maximun | n speed limit o | of the motor. Whe | en setting the tor | que cont | trol, the speed | limit must be |

The process principle is consistent with H07_19 torque control forward speed limit;

| | Description | Torque rea value | ches reference | Alter mode | Advanced configuration | factory default | 0 | Unit | 0.10% |
|--------|--------------------|---------------------|----------------|------------------|-----------------------------|------------------------|-------|-----------|--------|
| H07_21 | Parameter range | 0 | 3000 | Effective way | with immediate effect | Adaptatio n pattern | P/S/T | Data type | Uint16 |

Parameter H0B_02/H07_21/H07_22/H07_23 is used as the valid condition for the torque ToReach the output OutFun18 (ToReach). The relation is as follows:

The actual torque (H0B_02), the torque reaches the reference value (H07_21), the torque reaches the effective value (H07_22), and the torque reaches the invalid value (H07_23);

When the actual torque \geq torque reaches the reference value + torque reaches the effective value; The moment reaches the output OutFun18 (ToReach) effectively;

When the actual torque < torque reaches the reference value + torque reaches the invalid value; Moment reaches output OutFun18 (To Reach) invalid;

| | Description | Torque rea | ches effective | Alter | Advanced | factory | 200 | Unit | 0.10% |
|------------|--------------------|--------------|-------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| | Description | value | | mode | configuration | default | 200 | Olin | 0.1070 |
| H07_22 | Parameter range | 0 | 3000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| The effect | ive conditions for | r the torque | FoReach the outpu | it OutFun18 (| FoReach); | | | | |

| | Description | Torque rea | ches invalid | Alter mode | Advanced configuration | factory default | 100 | Unit | 0.10% |
|------------|--------------------|------------|------------------|------------------|-----------------------------|-----------------------|-------|--------------|--------|
| H07_23 | Parameter range | 0 | 3000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Invalid co | ndition for torque | ToReach ou | tput OutFun18 (T | oReach); | | | | | |

4.1.7 Performance and protection parameters (H08~H09~H0A)

| | Description | Velocity lo | oop gain | Alter mode | Advanced configuration | factory default | 200 | Unit | 0.1Hz |
|-------------|---|-------------|----------|------------------|-----------------------------|-----------------------|-----|-----------|--------|
| H08_00 | Parameter range | 1 | 20000 | Effective way | with immediate effect | Adaptation pattern | P/S | Data type | Uint16 |
| Setting the | g the speed loop gain can determine the speed loop to follow, changing the speed command maximum frequency; | | | | | | | | |
| Under the | condition that the motor does not have noise and vibration, increasing the value of this parameter appropriately can speed up the | | | | | | | | |
| positionin | positioning time and the following property; When noise and vibration occur, the value of this parameter is reduced; | | | | | | | | |

| | Description | Velocity lo integration constant | op time | Alter mode | Advanced configuration | factory default | 1000 | Unit | 0.01ms |
|-------------|--|--|------------|------------------|-----------------------------|-----------------------|------|-----------|--------|
| H08_01 | Parameter range | 15 | 51200 | Effective way | with immediate effect | Adaptation pattern | P/S | Data type | Uint16 |
| Setting the | Setting the speed loop integration time constant can eliminate the speed loop deviation; | | | | | | | | |

Reducing the setting value can strengthen the integral function and speed up the positioning time, but too small the setting value is easy to cause motor and mechanical vibration;

| | Description | Position lo | op gain | Alter mode | Advanced configuration | factory default | 100 | Unit | 0.1Hz |
|--------|--------------------|-------------|---------|------------------|-----------------------------|-----------------------|-----|-----------|--------|
| H08_02 | Parameter range | 0 | 20000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |

Setting the speed loop gain can determine the position loop to follow, changing the speed command maximum frequency; Under the condition that the motor does not have noise and vibration, increasing the value of this parameter appropriately can speed up the positioning time and improve the ability of resisting external disturbance when the motor is static. If the setting value is too large, the system may be unstable and oscillate.

| | Description | Load mor | nent of inertia | Alter | Advanced | factory | 0 | Unit | 0.01 times |
|--|--------------------|----------|-----------------|------------------|-----------------------------|-----------------------|-------|--------------|------------|
| | | ratio | | mode | configuration | default | | | |
| H08_15 | Parameter range | 0 | 12000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set the inertia ratio of mechanical load relative to the inertia of the motor itself; H08_15=0 indicates that the motor is not loaded. H08_15= | | | | | | | | ed. H08_15=1 | |
| indicates that the load inertia is equal to the motor inertia; | | | | | | | | | |

For high inertia load, increase the value of this parameter first and then adjust the gain.

| | Description | Speed feed | Speed feedforward gain | | Advanced configuration | factory default | 0 | Unit | 0.1% |
|--------|--------------------|------------|------------------------|------------------|-----------------------------|-----------------------|---|-----------|--------|
| H08_19 | Parameter range | 0 | 1000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |
| | | | | | | | | | |

Increasing this parameter can improve the position command response and reduce the position deviation at fixed speed.

| | Description | Self-adjus selection | ting mode | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|---|---|----------------------|-----------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H09_00 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set 0: invalid automatic adjustment of parameters (standard rigid table), manual adjustment of gain parameters; | | | | | | | | | |
| Set 1: the | Set 1: the standard rigid table is used, and the gain is automatically adjusted according to the rigid table level. | | | | | | | | |

| | Description | Selection | of rigidity level | Alter mode | Advanced configuration | factory default | 10 | Unit | - |
|--|--------------------|-----------|-------------------|------------------|-----------------------------|-----------------------|-------|----------------|--------|
| H09_01 | Parameter range | 0 | 41 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| When H09_00=1, set the motor rigidity according to the rigidity table level. The higher the rigidity level, the stronger the gain and the faster | | | | | | | | and the faster | |
| the response, but too strong rigidity will cause vibration; | | | | | | | | | |

| H0A_04 - | Description | Motor overload | | Alter | Enable | factory default | 100 | Unit | 0/2 |
|----------|-----------------|----------------|---------|-----------|-----------|-----------------|-------|-----------|----------|
| | Description | protectio | on gain | mode | OFF | lactory default | 100 | Unit | /0 |
| | Parameter range | 10 | 300 | Effective | with | Adaptation | P/S/T | Data type | I Unt 16 |
| | | 10 300 | | way | immediate | pattern | 1/5/1 | Data type | Omtro |

| | | | effect | | | |
|--|--|--|--------|--|--|--|
| | | | | | | |

By setting this parameter value, determine the motor overload fault alarm ER.620 reported time; 100% is about 10S, different motors have differences;

Setting this parameter should be determined according to the actual heating condition of the motor. If the electric machine is too large, the electric machine will exceed its torque for a long time and fail to load alarm, which will cause the motor temperature to be too high.

| | Description | Excessive position | | Alter | Advanced | factory | 1048576 | Unit | Encoder |
|------------|-----------------|---------------------------|------------|------------------|-----------------------------|-----------------------|---------|-----------|---------|
| | Description | deviation fault threshold | | mode | configuration | default | 1040570 | Oint | unit |
| H0A_10 | Parameter range | 1 | 1073741824 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt32 |
| Cat the me | | 1 | 1 | . 1.1 : | n made Defeat | 121072*0-104 | 0576 | | |

Set the position deviation too large overload alarm threshold in position mode; Default 131072*8=1048576, maximum 8 turns; When the deviation between the actual position of the motor and the command position exceeds this parameter value, a fault alarm will occur ER.B00;

| | Description | Motor o shieldin | overload g is enabled | Alter mode | Advanced configuration | factory default | 0 | Unit | Encoder unit |
|------------|---|---------------------|--------------------------|------------------|-----------------------------|-----------------------|-------|-----------|-----------------|
| H0A_26 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set 0: ope | Set 0: open motor overload detection alarm; | | | | | | | | |

Set 1: shield the motor overload detection alarm, and the motor will automatically run down after overload.

| H0A_36 | Description | Absolute shield se | e encoder fault election | Alter mode | Advanced configuration | factory default | 0 | Unit | - | |
|-------------|---|-----------------------|-----------------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|--|
| | Parameter range | 0 | 3 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 | |
| Set 0: mul | ti-turn absolute enc | oder norm | al application; | | | | | | | |
| Set 1: Scro | Set 1: Screening coil overflow detection; | | | | | | | | | |
| Set 2: Shie | Set 2: Shield battery status detection | | | | | | | | | |
| G (2 G1 · | | | | | | | | | | |

Set 3: Shielding coil overflow detection + battery status detection;

| H0A_44 | Description | Single-p overvolt value | hase bus age generated | Alter mode | Advanced configuration | factory default | - | Unit | V | |
|--|-----------------|-------------------------------|---------------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|--|
| | Parameter range | 24 500 | | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 | |
| Driver real-time single-phase bus voltage higher than the set value, overvoltage alarm | | | | | | | | | | |

| | Description | Single-p voltage value | hase bus undervoltage | Alter mode | Advanced configuration | factory default | - | Unit | V | |
|---|-----------------|------------------------------|--------------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|--|
| H0A_48 | Parameter range | 15 500 | | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 | |
| Driver real-time single-phase bus voltage below the set value, undervoltage alarm | | | | | | | | | | |

| | Description | Power-on initialization | | Alter | Advanced | factory | 1000 | Unit | ms | |
|---|-----------------|-------------------------|------|------------------|-----------------------------|-----------------------|-------|-----------|--------|--|
| | Description | delay tir | ne | mode | configuration | default | 1000 | | 1115 | |
| H0A_50 | Parameter range | 500 | 5000 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 | |
| Set the driver power-on initialization delay time | | | | | | | | | | |

| H0A_51 | Description | Undervo to gener | oltage continues ate alarm time | Alter mode | Advanced configuration | factory default | 10 | Unit | ms | |
|--|-----------------|---------------------|------------------------------------|------------------|-----------------------------|-----------------------|-------|-----------|--------|--|
| | Parameter range | 0 500 | | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 | |
| Alarm setting time when the drive continues to underdraw | | | | | | | | | | |

| | Description PUL | | DIR Signal | Alter | Advanced | factory | 0 | Unit | - |
|--------|-----------------|--------------------|------------|------------------|-----------------------------|-----------------------|---|-----------|--------|
| | | hardware filtering | | mode | configuration | default | | | |
| H0A_52 | 0 | 15 | 7 | Effective way | with immediate effect | Adaptation pattern | р | Data type | UInt16 |

Set 1: maximum receiving pulse frequency <300KHZ;

Set 2: maximum receiving pulse frequency <160KHZ;

Set 3: maximum receiving pulse frequency <070KHZ;

Set 4: maximum receiving pulse frequency <050KHZ;

Setting the appropriate filter level of pulse instruction can effectively prevent interference. The actual maximum pulse frequency is less than the allowable value of the selected filter level

4.1.8- Monitor read-only parameters (H0B)

| H0B_00 | Description | Real mo | otor speed | Alter mode | Display | factory default | - | Unit | rpm |
|--------|-----------------|------------|------------|------------------|---------|--------------------|---|-----------|-------|
| | Parameter range | -9999 9999 | | Effective way | - | Adaptation pattern | - | Data type | Int16 |
| (45) | | | | | | | | | |

| Display th | e real-time speed of | the moto | r after filtering; | | | |
|------------|----------------------|----------|--------------------|--|--|--|

| | Description | Internal r | eal-time torque | Alter mode | Display | factory default | - | Unit | 0.10% |
|--|--------------------|------------|-----------------|------------------|---------|-----------------------|---|-----------|-------|
| H0B_02 | Parameter range | -32767 | 32767 | Effective way | - | Adaptation pattern | - | Data type | Int16 |
| Display real-time internal torque output, 100.0% corresponding to the rated torque of the motor; | | | | | | | | | |

| H0B_03 | Description | Input signal (DI signal) monitoring | | Alter mode | Display | factory default | - | Unit | - |
|--|--------------------|--|-------|------------------|---------|-----------------------|---|-----------|--------|
| | Parameter range | 0 | 65535 | Effective way | - | Adaptation pattern | - | Data type | UInt16 |
| Displays d hardware DI port status in decimal notation. For example, if DI1 and DI3 are valid and other DO are invalid, the binary value is 00000101 and H0B_05 is displayed as 5 (decimal). | | | | | | | | | |

| H0B_05 | Description | Output sig | gnal (DO signal) | Alter mode | Display | factory default | - | Unit | - |
|--|--------------------|------------|------------------|------------------|---------|-----------------------|---|-----------|--------|
| | Parameter range | 0 | 65535 | Effective way | - | Adaptation pattern | - | Data type | UInt16 |
| Decimal display hardware DO port status; For example, if DO1 and DO2 are valid and other DO are invalid, the binary value is 00000011, | | | | | | | | | |

Decimal display hardware DO port status; For example, if DO1 and DO2 are valid and other DO are and H0B_05 is displayed as 3 (decimal).

| _ | Description | Absolute pos (32-bit decin | sition counter nal display) | Alter mode | Display | factory default | - | Unit | command unit |
|-----------------------|-----------------------------|-------------------------------|--------------------------------|------------------|-----------------|-----------------------|--------------|----------------|-----------------|
| H0B_07 | Parameter range | -999999999 | 999999999999 | Effective way | - | Adaptation pattern | - | Data type | Int32 |
| Display th cleared to | e real-time absolu zero; | te position of t | he motor (comm | nand pulse u | nit); After the | origin returns s | uccessfully, | the current po | sition will be |

| | Description | Enter the information | speed | Alter mode | Display | factory default | - | Unit | rpm |
|--------|--------------------|-----------------------|-------|------------------|---------|-----------------------|---|-----------|-------|
| H0B_11 | Parameter range | -6000 | 6000 | Effective way | - | Adaptation pattern | - | Data type | Int16 |

Display the rotational speed information corresponding to the command pulse input frequency, independent of enabling; This parameter can be used to test whether the external command pulse frequency is correct when OFF is enabled;

| | Description | Average | load ratio | Alter mode | PST | factory default | - | Unit | 0.10% |
|------------|---------------------|------------|--------------------|------------------|----------------|-----------------------|-------------|----------------|----------------|
| H0B_12 | Parameter range | 0 | 5000 | Effective way | - | Adaptation pattern | - | Data type | UInt16 |
| Display th | e real-time percent | age of the | average load of th | e motor in the | e rated torque | of the motor, 10 | 0.0% corres | ponding to the | e rated torque |

| | Description | Input comm counter (32-bit decir | Input command pulse counter (32-bit decimal display) | | Display | factory default | - | Unit | command unit |
|---|--------------------|--|--|------------------|---------|-----------------------|---|-----------|-----------------|
| H0B_13 | Parameter range | -999999999 | 999999999999 | Effective way | - | Adaptation pattern | - | Data type | Int32 |
| The number of display command pulse input is accumulated or decreased according to the direction, and has nothing to do with enabling; This parameter can be used to test whether the number of external instruction pulse input is correct when OFF is enabled. | | | | | | | | | |

| | Description | Encoder pos counter (32-bit decin | ition deviation nal display) | Alter mode | Display | factory default | - | Unit | Encoder unit |
|-----------|--------------------|---|---------------------------------|------------------|----------------|------------------------|--------|-----------|-----------------|
| H0B_15 | Parameter range | -999999999 | 99999999999 | Effective way | - | Adaptatio n pattern | - | Data type | Int32 |
| The motor | displays the real- | time deviatior | value between | the current po | sition and the | e command po | sition | | |

| | Description | AI1 Samplir | ng voltage | Alter mode | Display | factory default | - | Unit | 0.01V |
|------------|--------------------|----------------|----------------|------------------|---------|------------------------|---|-----------|--------|
| H0B_21 | Parameter range | 0 | 2000 | Effective way | - | Adaptatio n pattern | - | Data type | UInt16 |
| Displays t | he voltage value o | f the external | analog channel | 1 (AI1) input; | | | | | |

| - | Description | Effective current | value of phase | Alter mode | Display | factory default | - | Unit | 0.01A |
|-----------|--------------------|-------------------|----------------|------------------|---------|-----------------------|---|-----------|--------|
| H0B_24 | Parameter range | 0 | 10000 | Effective way | - | Adaptation pattern | - | Data type | UInt16 |
| Display m | otor real-time out | put phase cu | irrent value; | | | | | | |

| - | Description | Bus volta | ge value | Alter mode | Display | factory default | - | Unit | 0.1V |
|------------|----------------------|--------------|-------------------|------------------|---------------|-----------------------|------|-----------|--------|
| H0B_26 | Parameter range | 0 | 10000 | Effective way | - | Adaptation pattern | - | Data type | UInt16 |
| Display dr | vive real-time input | t bus voltag | e: Can be used to | monitor exter | nal power inp | ut voltage stabil | itv: | | |

Module temperature Alter factory Description Display Unit °C _ value default mode Adaptation H0B_27 Parameter Effective pattern 100 0 Data type UInt16 _ _ range way

Display the current drive MOS real-time temperature value;

| | Description | Error reco | ord | Alter mode | Advanced configuration | factory default | 0 | Unit | previous failures |
|---|-----------------------|-------------|---------------------|------------------|-----------------------------|------------------------|---|-----------|----------------------|
| H0B_33 | Parameter range | 0 | 9 | Effective way | with immediate effect | Adaptatio n pattern | - | Data type | UInt16 |
| It is used t | o set the faults of t | he motor fo | or the last 10 time | s; If no fault | records will not | be displayed; | | | |
| Set 0: H0B_34 to display the current fault information. | | | | | | | | | |

Set 1: H0B_34 displays the previous fault information.

Set.....

Set 9: H0B_34 displays the fault information of the last nine times.

| | Description | Selected r codes | number of fault | Alter mode | Display | factory default | - | Unit | - |
|-------------|--------------------|---------------------|--------------------|------------------|-----------------|-----------------------|---|-----------|--------|
| H0B_34 | Parameter range | 0 | 65535 | Effective way | - | Adaptation pattern | - | Data type | UInt16 |
| The fault i | nformation selecte | ed by H0B | 33 is displayed. E | by default, the | current fault i | s displayed. | | | |

| | Description | Absolute number d | encoder rotation ata | Alter mode | Display | factory default | - | Unit | r |
|------------|--|----------------------|-------------------------|------------------|---------|-----------------------|---|-----------|-------|
| H0B_70 | Parameter range | -32768 | 32767 | Effective way | - | Adaptation pattern | - | Data type | Int16 |
| Display at | isplay absolute value encoder rotation number data, single turn absolute value motor on the number of turns automatically reset; he absolute number of multi-turn motor turns is memorized; | | | | | | | | set; |

| | Description | Absolute encoder' within 1 | value of the s position turn | Alter mode | Display | factory default | - | Unit | Encoder unit |
|------------|--------------------|----------------------------------|------------------------------------|------------------|-----------------|-----------------------|--------|-----------|-----------------|
| H0B_71 | Parameter range | 0 | 2147483647 | Effective way | - | Adaptation pattern | - | Data type | UInt32 |
| Display at | osolute value enco | der positior | data in a single t | urn. AIMtor m | notor 1 turn su | bdivided into 13 | 31072: | | |

Absolute encoder Alter factory Encoder Description absolute position Display Unit mode default unit (Low 32 bits) H0B_77 Adaptation -99999 Parameter Effective pattern 99999999999 Data type Int32 999 range way

Display multi-turn absolute value motor based on absolute encoder position 32 bits lower;

Single-turn absolute value motor on the number of turns automatically cleared, the number of multi-turn absolute value motor turns memory;

| | Description | Absolute er absolute pc (high 32 bit | ncoder psition s) | Alter mode | Display | factory default | - | Unit | Encoder unit |
|-----------|--------------------|--|-------------------------|------------------|---------------|-------------------------|---------------|---------------|-----------------|
| H0B_79 | Parameter range | -999999999 | 999999999999 | Effective way | - | Adaptation pattern | - | Data type | Int32 |
| Display m | ulti-turn absolute | value motor ba | ased on absolute | e encoder pos | ition high 32 | bits; umber of multi | turn absolute | a valua motor | turne |
| memory; | | | | | | | | ums | |

4.1.9-RS485 communication and function parameters (H0C)

| | Description | Servo axis | s address | Alter mode | Advanced configuration | factory default | 1 | Unit | - |
|--------|--------------------|------------|-----------|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| H0C_00 | Parameter range | 1 | 247 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |

Set the servo shaft address;

AIMotor supports broadcast mode (in broadcast mode, the host can only write to the slave station, and the slave station executes according to the command received from the master station but does not return data).

When a host controls multiple slave stations, it is necessary to ensure that each slave station has a unique axis address, which cannot be repeated, otherwise the communication will fail.

| | Description | Serial po setting | rt baud rate | Alter mode | Advanced configuration | factory default | 5 | Unit | - |
|-----------|--------------------|----------------------|-----------------|--|--|-----------------------|---------------|------------------|-----------------|
| H0C_02 | Parameter range | 0 | 6 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | Uint16 |
| Set servo | shaft communicat | ion baud rat | e, factory defa | ult 57600; The | e baud rate of the | servo axis mus | t be consiste | ent with that of | f the host, |
| otherwise | communication c | annot be est | established; | | | | | | |
| Settin | ng Value | | Baud rate | | | | Remark | | |
| | 0 | | 2400kbp/s | | The lower the b | baud rate, the sl | ower the cor | nmunication s | peed and the |
| | 1 | | 4800kbp/s | | less susceptible | e to external sign | nals. | | |
| | 2 | | 9600kbp/s | | When connecting the debugging software of the manufacturer's upper | | | | |
| | 3 | | 19200kbp/s | | computer, it is smooth. | recommended t | o use high b | aud rate, whic | h is more |
| | 4 | | 38400kbp/s | | The higher the | baud rate, the fa | aster the con | nmunication s | peed is, and it |
| | 5 | | 57600kbp/s | | is relatively eas | sy to be interference | ed by extern | al signals. | |
| | 6 115200kbp/s | | | It is recommended to use low baud rate to ensure communication stability in case of severe electromagnetic or long-distance communication. | | | | nication ce | |

| | Description | MODBU | JS data format | Alter mode | Advanced configurat ion | factory default | 0 | Unit | - |
|--|--------------------|-------|----------------|------------------|-------------------------------|-----------------------|-------|-----------|--------|
| H0C_03 | Parameter range | 0 | 3 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set the servo shaft communication data verification mode; Servo axis Modbus data format is consistent with the host; | | | | | | | | | |

| | Description | Whether communi updated t | the MODBUS cation write is o the EEPROM | Alter mode | Advanced configurat ion | factory default | 0 | Unit | - |
|---|--------------------|---------------------------------|---|------------------|-------------------------------|-----------------------|---------------|-----------|--------|
| H0C_13 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| The parameter value changed by communication is saved in the temporary storage area for effect. After power failure, the parameter will be restored to the value before the change. This parameter determines whether to permanently save the modified parameter value. | | | | | | | meter will be | | |

Set 1: Save the parameters changed by communication into EEPROM, and automatically set to 0 if the parameters are saved successfully;

4.1.10- Auxiliary function parameters (H0D)

| | Description | Software res | et | Alter mode | Enable OFF | factory default | 0 | Unit | - |
|------------|--------------------|--------------|---------------------|------------------|-----------------------------|-----------------------|--------------|------------------|-----------------|
| H0D_00 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set 1: the | software of the | motor system | is reset and restar | ted, similar to | the effect of p | oower-off restar | t; Automatic | ally set to 0 at | fter successful |

reset;

| I | Description | Error reset | | Alter mode | Enable OFF | factory default | 0 | Unit | - |
|-------------|--------------------|----------------|-------------------|------------------|-----------------------------|-----------------------|--------------|----------------|--------|
| H0D_01 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set 1: rese | et driver fault al | arm state (som | e fault alarms do | not support fa | ult reset need | to check the rea | son after po | ower restart); | |

| H0D_05 | Description Parameter | E-STOP | 1 | Alter mode Effective | Advanced configuration with immediate | factory default Adaptation pattern | 0 P/S/T | Unit Data type | - UInt16 |
|--|--------------------------|--------------|---------------|----------------------------|--|---|--------------|-------------------|-------------|
| Set 0; Lift | emergency shut | down; Set 1: | internal emer | gency stop, the | effect e motor immediat | ely stop after en | nergency sto | p to keep the j | position |
| lockeu, | | 41 1 4 | 1 1 | 4.14 | . 1 1 | 6 (| | | |
| | Description | reset enable | d | mode | configuration | default | 0 | Unit | - |
| H0D_20 | Parameter range 0 2 | | 2 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |
| Set 0; Have no effect; Set 1: Reset the internal fault information of the absolute encoder; Set 2: Reset the internal fault information of absolute encoder + clear multi-circle data; | | | | | | | | | |

4.1.11- Internal multibit parameters (H11)

| H11_00 | Description | Multi-segme | ent position | Alter | Enable | factory | 1 | Linit | |
|--------|-------------|--------------|--------------|-----------|-----------|------------|---|-----------|----------|
| | Description | operation mo | ode | mode | OFF | default | | | - |
| | Parameter | 0 | 5 | Effective | with | Adaptation | р | Data type | I Unt 16 |
| | range | 0 | 5 | way | immediate | pattern | I | Data type | Omrio |

| | | | | effect | | | | | | |
|---|---|--|--|---|--|--|--|--|--|--|
| If H02_00 | =1 selects the position co | ontrol mode and H05_ | 00=2 selects the | he position co | mmand from m | ultiple segm | ents, set the m | ulti-segment | | |
| operation | mode in the following tal | ole | | | | | | | | |
| Setting value | Running way | | | | Remark | | | | | |
| 0 | Stop at the end of singl cycle operation | e It will stop after effective. The s segment, and a | r running for 1 egment numbe waiting time c | round, and w er is automatic can be set betw | ill start to run w ally incremente veen segments. I | hen the mul d from the f Multi-bit OF | lti-stage enabl irst segment to FF, force stop; | e level is the final | | |
| 1 | Cycle running | Cyclic operation automatically in completes the w stop; | Cyclic operation, multi-segment enable level when the start of operation; The segment number is automatically incremented from the first segment to the final segment. After the final segment completes the waiting time, it automatically repeats from the first segment. Multi-bit OFF, force stop; | | | | | | | |
| 2 | DI switching operation | To set the DI sw running instruct InFun6 (CMD1 The number of (position/speed There is no wai terminal is logic Run when the r | vitching opera- tion switching) InFun7 (CM segments to ru /acceleration/d ting time betw cally determin- ising edge is tr | tion, there mu D2) multi-seg in is determine leceleration pr veen segments ed, you need t riggered. The o | st be at least one ment switch ins ed by the DI terr e-set within the depending on t o enable the mu combination log | e DI associa truction 1, 2 ninal combi segment); he timing o lti-bit funct ic of DI terr | ted with multi 2; ination logic f the call; Afte ion minals is show | -segment or the DI on in Note 2. | | |
| Note 1: Al Note 2: D | l multi-bit running mode switching operation cor | s must associate DI w nbination logic is as fo | ith an InFun28 ollows: | 8 (PosInSen) n | nulti-bit enable. | | | | | |
| Multista | ge switching | Multistage switching | 2 | Multi-segme | nt enable | Runn | ing position s | egment | | |
| Instruction 1 (CMD1) Instruction 2 (CMD2) (Po | | | | | | | | | | |
| OFF OFF | | | | $OFF \rightarrow ON$ | | 1 | | | | |
| ON | | OFF | | $OFF \rightarrow ON$ 2 | | | | | | |
| OFF | | ON | | $OFF \rightarrow ON$ 3 | | | | | | |
| ON | ON ON OFF \rightarrow ON 4 | | | | | | | | | |

| | Description | Number of e | end segments of | Alter | Enable | factory | 1 | Unit | _ |
|--------|--------------------|-------------|-----------------|------------------|-----------------------------|-----------------------|---|-----------|--------|
| | Description | displacemen | t command | mode | OFF | default | 1 | Oint | |
| H11_01 | Parameter range | 1 | 4 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

Set the total number of multi-segment running, different number of segments can be set different displacement, speed, acceleration and deceleration time;

When the multi-segment running mode $\neq 2$, the multi-segment segment number is automatically increased and the switching sequence is 1,2... H11_01 end segment;

| | Description | Allowance tr | eatment method | Alter mode | Enable OFF | factory default | 0 | Unit | - |
|--------|--------------------|--------------|----------------|------------------|-----------------------------|-----------------------|---|-----------|--------|
| H11_02 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |

When the multi-bit operation mode =0/1, if the mode is switched or the multi-bit enable signal changes from ON to OFF in the multi-bit operation, the operation is suspended and the processing mode is re-run;

Set 0: continue to run the number of remaining segments. If the last run is suspended in the middle of the second segment, the re-run will abandon the remainder of the second segment 2 and continue to run from the third segment;

Set 1: Restart the operation from the first segment. If the last operation is suspended in the middle of the second segment, the restart will abandon the remaining segments and restart the operation from the first segment.

| | Description | Displacemen type selection | t instruction | Alter mode | Advanced configurat ion | factory default | 0 | Unit | - |
|--------|--------------------|-------------------------------|---------------|------------------|-------------------------------|-----------------------|---|-----------|--------|
| H11_04 | Parameter range | 0 | 1 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |

Set 0: Relative shift instruction (incremental shift instruction based on current position)

Set 1: Absolute displacement instruction (incremental displacement instruction based on zero (origin) coordinates)

As shown in the figure, the current position of the motor is 200. If the relative position instruction is executed, the displacement is 100.

Then the motor finally moves to 200+100=300 position;

As shown in the figure, the current position of the motor is 200. If the absolute position instruction is executed, the displacement is 100.

Then the motor finally moves to the 0+100=100 position;



| | Description | Sequential m starting segn | node runs nent selection | Alter mode | Enable OFF | factory default | 0 | Unit | - |
|--------|--------------------|-------------------------------|-----------------------------|------------------|-----------------------------|-----------------------|---|-----------|--------|
| H11_05 | Parameter range | 0 | 4 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |

When $H11_00=3$, $H11_05=0$: indicates that the sequence runs from segment 1 to the end of a single cycle.

When H11_00=3, H11_05 \neq 0: indicates that the sequence runs from segment 1 to the end segment and then the number of segments set by this parameter is the starting segment to continue the cycle sequence.

| | Description | Paragraph 1 displacement | moves the | Alter mode | Advanced configurat ion | factory default | 1000 | Unit | command unit |
|--------|--------------------|--------------------------|------------|------------------|-------------------------------|-----------------------|------|-----------|-----------------|
| H11_12 | Parameter range | -10737418 24 | 1073741824 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Int32 |

When H11_04=0 relative displacement command, set the relative displacement increment of the first segment of multi-segment position. Motor movement direction depends on the set positive and negative;

When H11_04=1 absolute displacement command, the first segment of multi-segment position is set to move the target position. The motor movement direction depends on the current position and the coordinate direction of the target position.

The same is true for the following other segments;

| | Description | Maximum runr | ning speed of | Alter | Advanced | factory | 2.00 | Unit | rpm |
|-------------|---|---------------------|-------------------|------------------|-----------------------------|-----------------------|-------------|-----------------|--------------|
| | Desemption | displacement ir | n section 1 | mode | configuration | default | 200 | Cint | 19 |
| H11_14 | Parameter range | 1 | 6000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |
| Set the hig | shest speed to p | perform the first s | stage of position | on operation; | When the displac | ement is very s | mall, the m | otor will start | to slow down |
| in the proc | cess of acceleration, and the stop position will not reach the maximum speed. | | | | | | | | |
| The same | e same is true for the following other segments; | | | | | | | | |

| | Description | Section 1 dis acceleration a time | placement and deceleration | Alter mode | Advanced configuration | factory default | 10 | Unit | ms |
|-------------|--------------------|---|-------------------------------|------------------|-----------------------------|-----------------------|---------|---------------|--------------|
| H11_15 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Uint16 |
| Set the acc | celeration time | of 0-1000rpm | and deceleration t | ime of 1000-0 | orpm when execu | ting the first seg | ment of | position. The | same is true |
| for the fol | lowing other se | gments; | | | | | | | |
| The same | is true for the f | ollowing other | segments; | | | | | | |

| | Description | Wait time aft | er the | Alter | Advanced | factory | 10 | Unit | ma |
|------------|--------------------|------------------|---------------------|------------------|-----------------------------|-----------------------|------------|----------------|------------|
| | Description | completion o | f the first shift | mode | configuration | default | 10 | Unit | 1115 |
| H11_16 | Parameter range | 0 | 10000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |
| Set the de | lay time to paus | se the setting a | fter the end of the | e first segme | nt, and then exec | ute the next segr | nent; | | |
| This para | meter is invalid | when H11_00 | =2 (DI switching | H hae (anir | $11 \ 00=3$ (sequer | tial runs) The s | me is true | for the follow | ving other |

This parameter is invalid when H11_00=2 (DI switching runs) and H11_00=3 (sequential runs). The same is true for the following other segments;

| | Description | Paragraph 2 | moves the | Alter | Advanced | factory | 1000 | Unit | Instruction |
|--------|--------------------|-----------------|------------|------------------|-----------------------------|-----------------------|------|-----------|-------------|
| | Description | displacemen | t | mode | configuration | default | 1000 | Unit | Unit |
| H11_17 | Parameter range | -10737418 24 | 1073741824 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Int32 |

| | Description | Section 2 dis | splacement | Alter | Advanced | factory default | 200 | Unit | rpm |
|--------|--------------------|---------------|------------|-----------|-----------------------------|-----------------------|-----|-----------|--------|
| H11_19 | Parameter range | 1 | 6000 | Effective | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

| | Description | Section 2 dis acceleration deceleration | placement and time | Alter mode | Advanced configuration | factory default | 10 | Unit | ms |
|--------|--------------------|---|--------------------------|------------------|-----------------------------|-----------------------|----|-----------|--------|
| H11_20 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

| | Description | Wait time aff completion of shift | ter the | Alter mode | Advanced configuration | factory default | 10 | Unit | ms |
|--------|--------------------|---|---------|------------------|-----------------------------|-----------------------|----|-----------|--------|
| H11_21 | Parameter range | 0 | 10000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

| | Description | Paragraph 3 displacemen | moves the t | Alter mode | Advanced configuration | factory default | 1000 | Unit | Instruction unit |
|--------|--------------------|----------------------------|----------------|------------------|-----------------------------|-----------------------|------|-----------|---------------------|
| H11_22 | Parameter range | -10000000 | 10000000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Int32 |

| | Description | Section 3 dis maximum ru | splacement | Alter mode | Advanced configuration | factory default | 200 | Unit | rpm |
|--------|--------------------|-----------------------------|------------|------------------|-----------------------------|-----------------------|-----|-----------|--------|
| H11_24 | Parameter range | 1 | 6000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

| H11_25 | Description | Section 3 displacement acceleration and deceleration time | Alter mode | Advanced configuration | factory default | 10 | Unit | ms |
|--------|-------------|---|---------------|------------------------|--------------------|----|------|----|
|--------|-------------|---|---------------|------------------------|--------------------|----|------|----|

| | Description | Wait time af | ter the | Alter | Advanced | factory | 10 | Linit | 100 G |
|---------|--------------------|---------------|--------------------|------------------|--------------------------|------------|----|-----------|--------|
| | Description | completion of | of the Third shift | mode | configuration | default | 10 | Unit | IIIS |
| H11 26 | | | | | | Adaptation | | | |
| 1111_20 | Parameter range | 0 | 10000 | Effective way | with immediate effect | pattern | Р | Data type | UInt16 |

| Desc | Description | Paragraph 4 | moves the | Alter | Advanced | factory | 1000 | ∐nit | Instruction |
|--------|--------------------|-------------|-----------|------------------|-----------------------------|-----------------------|------|-----------|-------------|
| | Description | displacemen | t | mode | configuration | default | 1000 | Oint | unit |
| H11_27 | Parameter range | -10000000 | 10000000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | Int32 |

| | Description | Section 4 dis maximum ru | splacement | Alter mode | Advanced configuration | factory default | 200 | Unit | rpm |
|--------|--------------------|-----------------------------|------------|------------------|-----------------------------|-----------------------|-----|-----------|--------|
| H11_29 | Parameter range | 1 | 6000 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

| | Description | Section 4 dis acceleration deceleration | placement and time | Alter mode | Advanced configuration | factory default | 10 | Unit | ms |
|--------|--------------------|---|--------------------------|------------------|-----------------------------|-----------------------|----|-----------|--------|
| H11_30 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | Р | Data type | UInt16 |

| H11_31 | Description | Wait time after the completion of the Forth shift | Alter mode | Advanced configuration | factory default | 10 | Unit | ms |
|--------|-------------|---|---------------|------------------------|--------------------|----|------|----|
|--------|-------------|---|---------------|------------------------|--------------------|----|------|----|

4.1.12-Internal multi-stage velocity parameter (H12)

| | Description | Multi - spee | d command | Alter | Enable | factory | 1 | Unit | - | |
|----------------------|-------------------------------|------------------|--|---|---|---|---|---|---|--|
| H12_00 | Parameter range | 0 operation m | 2 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 | |
| When H02 | 2_00=0 selects t | he position co | ontrol mode and H | 06_00=1 sele | cts the speed o | command from | multi-speed, | , set the multi- | speed | |
| Set | Running | g mode | | | | Remark | | | | |
| 0 | Stop at the en- | d of single n | The machine wi is effective. The segment, and th motor stops acco | ll stop after ru segment num e running time ording to the e | inning for 1 ro iber is automa e of each segm enabled OFF n | bund, and the set tically increment nent can be set. 7 node set by H02 | rvo enable long nted from the The servo is 2_05; | evel will start e first segmen enabled to Ol | to run when it t to the final FF, and the | |
| 1 | cycle operatio | n | Cyclic operation, start operation when the servo enable level is effective; The segment number is automatically incremented from the first segment to the final segment, and the running time of each segment can be set. When the running time of the end section is finished, the loop is repeated from the first section. The servo is enabled to OFF, and the motor stops according to the enabled OFF mode set by H02_05; | | | | | | | |
| 2 | DI Switchove | r Operation | To set the DI so multi-segment InFun6 (CMD1 The number of DI terminal con Each time the segment will b | witching ope running inst InFun7 (CM segments (i mbination log DI terminal lo e switched ir | ration, there truction swite D2) multi-se ntra-segmen gic; ogic is detern nmediately. | must be at lea :hing. gment switch i t speed/segme nined and the | st one DI a instruction ent running servo is en | ssociated wit 1, 2; 9 time) detern abled, the cc | th mined by the prresponding | |
| Note 1: D | I switching op | eration com | bination logic is | as follows: | | | | | | |
| Multista Instruct | ige switching ion 1 (CMD1) | Mi | ultistage switchir struction 2 (CMD | ng 2) | Enable(SON) |) | Runn | ing speed ra | nge | |
| OFF | OFF OFF | | | | | | 1 | | | |
| ON | | OF | F | | ON | | 2 | | | |
| OFF | | ON | J | | ON | | 3 | | | |
| ON | ON ON 4 | | | | | | | | | |

| | Description | Speed comm segment num | and end | Alter mode | Enable OFF | factory default | 4 | Unit | - |
|-------------|---|---------------------------|--------------------|------------------|-----------------------------|-----------------------|--------------|---------------|-------------|
| H12_01 | Parameter range | 1 | 4 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |
| Set the tot | al number of m | ulti-speed run | ning segments, dif | fferent numbe | r of segments | can be set diffe | rent running | speed and rur | nning time; |
| When the | When the multi-segment running mode $\neq 2$, the multi-segment speed segment number is automatically increased and the switching sequence | | | | | | | | |

is 1,2... H12_01 end segment;

| | Description | acceleration | acceleration time | | Advanced configuration | factory default | 10 | Unit | ms |
|--|--------------------|---------------|-------------------|------------------|-----------------------------|-----------------------|--------------|----------------|----------------|
| H12_03 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |
| Set the acc | celeration time | from 0-1000rp | m; When swite | ching from seg | gment to segment | t, the motor wil | l automatica | lly accelerate | and decelerate |
| smoothly. The number of all segments is universal; | | | | | | | | | |

| | Description | deceleration | time | Alter mode | Advanced configuration | factory default | 10 | Unit | ms |
|--------|--------------------|--------------|------------|------------------|-----------------------------|-----------------------|----|-----------|--------|
| H12_04 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |
| 0.11 | 1 | C1000 0 | 1111 . 1 . | C | | | | 1 . | |

Set the acceleration time of 1000-0rpm; When switching from segment to segment, the motor will automatically accelerate and decelerate smoothly. The number of all segments is universal;

| | Description | Paragraph 1 command | Speed | Alter mode | Advanced configuration | factory default | 0 | Unit | rpm |
|--------|--------------------|------------------------|-------|------------------|-----------------------------|-----------------------|---|-----------|-------|
| H12_20 | Parameter range | -6000 | 6000 | Effective way | with immediate effect | Adaptation pattern | S | Data type | Int16 |

Set the maximum speed to perform the first speed run; Motor movement direction depends on the set positive and negative; The same is true for the following other segments;

| D | Description | Paragraph 1 | indicates the | Alter | Advanced | factory | 50 | Unit | 0.1s |
|--------|--------------------|--------------|---------------|------------------|-----------------------------|-----------------------|----|-----------|--------|
| | Description | running time | • | mode | configuration | default | 50 | Oint | 0.15 |
| H12_21 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |

Set the time to execute the first speed run; Time to reach this section of the run is complete; The same is true for the following other segments;

| H12_23 Descr | Description | Paragraph2 Speed | Alter | Alter Advanced | | 100 | Unit | ram |
|--------------|-------------|------------------|-------|----------------|---------|-----|------|-----|
| | Description | command | mode | configuration | default | 100 | Unit | Ipm |

| H12_24 | Description | Paragraph2 indicates the running time | Alter mode | Advanced configurat ion | factory default | 50 | Unit | 0.1s |
|--------|-------------|---------------------------------------|---------------|-------------------------------|--------------------|----|------|------|
|--------|-------------|---------------------------------------|---------------|-------------------------------|--------------------|----|------|------|

| | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |
|--|--------------------|---|-------|------------------|-----------------------------|-----------------------|---|-----------|--------|
|--|--------------------|---|-------|------------------|-----------------------------|-----------------------|---|-----------|--------|

| | Description | Paragraph 3 command | Speed | Alter mode | Advanced configuration | factory default | 300 | Unit | rpm |
|--------|--------------------|---------------------|-------|------------------|-----------------------------|------------------------|-----|-----------|-------|
| H12_26 | Parameter range | -6000 | 6000 | Effective way | with immediate effect | Adaptatio n pattern | S | Data type | Int16 |

| | Description | Paragraph 3 | indicates the | Alter | Advanced | factory | 50 | Unit | 0.1s |
|---------|--------------------|--------------|---------------|------------------|-----------------------------|-----------------------|----|-----------|--------|
| Descrip | Description | running time | | mode | configuration | default | 30 | Unit | 0.15 |
| H12_27 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |

| | Description | Paragraph4 Speed | | Alter | Advanced | factory | 500 | Unit | rnm |
|--------|--------------------|------------------|------|------------------|-----------------------------|-----------------------|-----|-----------|-------|
| | Decomption | command | | mode | configuration | default | 500 | Olin | ipin |
| H12_29 | Parameter range | -6000 | 6000 | Effective way | with immediate effect | Adaptation pattern | S | Data type | Int16 |

| | Description | Paragraph 4 | indicates the | Alter | Advanced | factory default | 50 | Unit | 0.1s |
|--------|--------------------|--------------|---------------|------------------|-----------------------------|-----------------------|----|-----------|--------|
| | Description | running time | | mode | configuration | lactory default | 50 | Unit | 0.15 |
| H12_30 | Parameter range | 0 | 65535 | Effective way | with immediate effect | Adaptation pattern | S | Data type | UInt16 |

5.1 communication interface





D-AIS22030、D-AIS22050、 D-AIS380100、D-AIS380150、D-AIS380200

| communication interface | 485A send pin | 485B receive pin | GND Pin | | | | |
|-----------------------------|---|------------------|---------|--|--|--|--|
| RJ45 net opening | 4 | 4 5 | | | | | |
| 1394 socket | 6 | 5 | 2 | | | | |
| The communication | The communication distance using twisted-pair shielded cables is up to 500m, and within 300m is | | | | | | |
| recommended for normal use. | | | | | | | |

5.2 RS485 communication cable

Multiple slave station connections



Note 1: If the communication signal is noisy, it is recommended to add a 120 ohm terminal resistor to the last slave station to ensure the communication quality;

Note 2: Communication related review (4.1.9 Section RS485 related parameters)

60

Connects to the upper computer for debugging



Note 1: Usually there is no direct 485 interface on the computer, you need to convert the USB to 485 to connect to the slave motor drive.

Note 2: We can download the PC debugging software on the official website, which is convenient for users to debug. (www.sihengmotor.com)

5.3 Introduction to communication protocols

The servo driver is embedded with the standard Modbus RTU communication protocol, which supports the operation of reading and writing single or multiple parameters by the Modbus RTU master station. When there is Modbus

After the protocol controller is successfully connected to the servo driver, the controller can directly perform parameter setting, monitoring and reading operations on the servo driver. The servo drive is in In the communication control mode, the controller can modify the position, speed, and torque operation command parameters in real time to change the motor's operating position, speed, and torque.

The mapping between the function ID of the driver and the Modbus address of the device is as follows:

| Parameter F | function No. | Caculation mode | Modbus address | | | | |
|---|--------------|--|----------------|--|--|--|--|
| hexadecimal | 10hex | (hexadecimal group number) \times 256 + (decimal group | 10hex | | | | |
| | | | | | | | |
| H02 | 00 | 02 (02)×256 + 00 | 512 | | | | |
| H0C | 12 | 0C(12)×256 + 13 | 3085 | | | | |
| H11 | 04 | 11(17)×256 + 04 | 4356 | | | | |
| Parameter Function group number (hexadecimal) x 256+ Parameter group address number (decimal) = Modbus register | | | | | | | |
| control address (decimal) | | | | | | | |

Modbus RTU protocol has a variety of bus commands, the servo driver supports the most commonly used three kinds of function code commands (03H/06H/10H), these three kinds of function code commands can meet the controller's omnidirectional control of the servo driver.

1: Communication read/write parameter data length

The Modbus register is 16 bits long. Pay attention to the data type of the access parameter when using the Modbus command.

Parameter data type is UInt16, Int16 should use function code 03H read, 06H write;

Parameter Data type: Int32 or read/write multiple parameters using function code 03H for reading and 10H for writing.

61

2:03H(read a single register)

If a parameter is read only with FUNCTION code 03H, the register starts at the register address for that parameter. The return data is the data corresponding to the parameter.

Example: The host sends the following request data frame to read the driver communication address station number 01 and parameter number H0B_00 (current motor speed) data.

The H0B_00 register address is 0B00H; The number of read registers is 1(data type Int16); Send request needle \downarrow ;

| Slave address | Function No | Register start address high order | Register start address low order | Read the high order of the number of registers | Read the low order of the number of registers | CRC check high bit | CRC check lower bit |
|---------------|-------------|---|--|---|---|-----------------------|------------------------|
| 01H | 03H | 0BH | 00H | 00H | 01H | 86H | 2EH |

Assume that the current speed of the motor is 0, and the correct return of the driver is \downarrow . The return start address data is H0B 00 data.

| Slava addross | Eurotion No. | Return the length of | Return start address | Reti | urn start address | CRC check | CRC check high |
|---------------|--------------|----------------------|----------------------|--------------|-------------------|-----------|----------------|
| Slave address | Function No | data bytes | data high bit | data low bit | | high bit | bit |
| 01H | 03H | 02H | 00H | 00 | B8I | ł | 44H |
| | | | | Н | | | |

3:06H(Write a single register)

The 06H function code can only write a 16-bit data length parameter, the register starting address is the register address of the parameter, the driver will receive the request data frame after the success of this parameter value changed to write data; For example, the host sends the following request data frame and writes data 1 to drive communication address station 01 and parameter H02_00 (control mode selection).

H02_00 register address is 0200H; The write data is 1 and the data type is Int16. Send the request needle ↓

| Slave address | Function No | Register start address high order | Register start address low order | Write register data high bits | Write register data low bits | CRC check high bit | CRC check high bit |
|---------------|-------------|---|--|----------------------------------|---------------------------------|-----------------------|--------------------|
| 01H | 06H | 02H | 00H | 00H | 01H | 49H | B2H |
| TT1 1 C | | 11 /1 1. | | . 1 | | | |

The value of \downarrow H0B_00 returned by the drive will be changed to 1.

| Slave address | Function No | Register start address high order | Register start address low order | Received register data high bits | Received register data low bits | CRC check high bit | CRC check high bit |
|---------------|-------------|---|--|--|------------------------------------|-----------------------|--------------------|
| 01H | 06H | 02H | 00H | 00H | 01H | 49H | B2H |

4:03H(Read successive registers)

Parameter table Some parameters are of 32-bit data type, and some parameters have jumps. For example, the next parameter of H0B_00 is H0B_02. If you want to read multiple parameter data continuously, you need to use 03H function to read multiple 16-bit registers continuously. When 03H is used to read consecutive parameters, the register starts at the register address of the first parameter. Return continuous data in the order of the first parameter data \rightarrow the second parameter data \rightarrow the NTH parameter data; The system is based on the return of the first parameter data automatically sequentially offset, the amount of data returned depends on the number of read registers;

Example: The host sends the following request data frame, reads the driver communication address station number is 01, the parameter number is H0B_02 (motor real-time torque) and its next parameter H0B_03(input DI monitoring) and its next parameter H0B_05(output DO monitoring) three parameter data.

The register address of the start parameter H0B_02 is 0B02H. The parameter data type is H0B_02(Int16), H0B_03(UInt32), H0B_05(UInt16), number of registers to read according to the parameter data type is 4. Send request needle \downarrow ;

| Slave address | Function No | Register start address high order | Register start address low order | Read the high order of the number of registers | Read the low order of the number of registers | CRC check high bit | CRC check high bit |
|---------------|-------------|---|--|---|---|-----------------------|-----------------------|
| 01H | 03H | 0BH | 02H | 00H | 04H | E7 | ED |

Assume that the current parameter values H0B_02=100, H0B_03=1, and H0B_02=3 drive correctly returns the reply pin as

Ļ

| Slave address | Function No | return data byte length | Return start address data high bit | Return start address data low bit | Return starting address + 1 high data bit | Return starting address + 1 low data bit | Return starting address + 2 high | Return starting address + 2 low data bit | Return starting address + 3 high | Return starting address +3low data bit | CRC check high bit | CRC check high bit |
|------------------|----------------|----------------------------------|--|---|---|--|--|--|--|--|--------------------------|--------------------------|
| | | | | | | | data bit | | data bit | | | |
| 01H | 03H | 08H | 00H | 64H | 00H | 00H | 00H | 01H | 00H | 03H | A1H | D0H |
| | | | H0B_02 | parameter | H0B_ | 03 Paramete | er Returned | value | H0B_05 | parameter | | |
| | | | return | value | (Lower 1 | 6 bits in fro | ont, higher | 16 bits in | retur | n value | | |
| | | | | | | bao | ck) | | | | | |

5: 10H(Write to multiple registers in succession)

Parameter table Some parameters are of 32-bit data type, and some parameters have jumps. For example, the next parameter of H05_04 is H05_07. If you want to write multiple parameter data consecutively, you need to write multiple 16-bit registers consecutively using the 10H function code. When using 10H to read consecutive parameters, the register address starts with the first parameter's register address. Write continuous data in the order of the first parameter data \rightarrow the second parameter data \rightarrow the NTH parameter data; The system is automatically sequentially offset according to the received first parameter data, written data;

Example: THE host sends the following request data frame, writing the drive communication address station number 01, parameter number H11_12 (segment 1 displacement) to 1000 and its next parameter H11_14(segment 1 maximum speed) to 200.

The register address of the start parameter H11_12 is 110CH. The parameter data types are H11_12(Int32), H11_14(UInt16); The number of registers written according to the parameter data type is 3; Send request needle \downarrow ;

| | | Regist | Register | Write | Write | numbe | Start | Start | Start | Start | Start | Start | | |
|--------|--------|--------|----------|---------|---------|--------|--------|-------------|-----------|--------|--------|-----------|----------|----------|
| Slava | | er | start | registe | registe | r of | addres | addres | addres | addres | addres | address | CDC | CBC |
| Slave | Functi | start | address | r | r | bytes | s data | s data | s + 1 | s + 1 | s +2 | +2 data | ckt | ckc |
| addres | on No | addres | low | numbe | numb | writte | high | low | data | data | data | low order | bish hit | bigh hit |
| S | | s high | order | r high | er low | n | order | order | high | low | high | | nign bit | nign bit |
| | | order | | | | | | | order | order | order | | | |
| 01H | 10H | 11H | 0CH | 00H | 03H | 06H | 00H | 00H | 03H | E8H | 00H | C8H | F7H | 65H |
| | | | | | | | Da | ata writter | 1 by H11_ | 12 | H11 | _14data | | |

The value of \H11_12 is changed to 1000. H11_14 will be changed to 200;

| Slave address | Function No | Register start address high order | Register start address low order | Received register count high order | Received register count low order | CRC check high bit | CRC check high bit |
|------------------|-------------|---|--|------------------------------------|--------------------------------------|--------------------|--------------------|
| 01H | 10H | 11H | 0CH | 00H | 03H | 45H | 37H |

6:Communication error code

If the MASTER sends an INCORRECT data frame or the slave server receives an error message from the master due to interference during communication, the slave will return an error data frame in the following format

| Slave address | Function error code | Error number | CRC check high bit | CRC check high bit |
|---|---|--|--------------------------|---------------------------|
| Return according to the actual communication station number | (When using 03H code) = 83H (When using 06H code) = 86H (When using 10H code) = 90H | (Function code error) =01H (parameter address error)=02H (CRC check error)=04H | Checksum based byte v | on the first three values |

5.2-Communication control scheme

1:Communication controls the speed of operation

First, use the debugging software of the upper computer to set the following parameters in advance

| Parameter No | Set | Function description | Modification | Effective | parameter | Data type |
|--------------|-------|---|--------------|-------------|-----------|-----------|
| | Value | | | way | range | |
| H02_00 | 0 | Control mode selection: speed control | Enable | Effective | 0~2 | UInt16 |
| | | | disconnect | immediately | | |
| H03_02 | 1 | DI1 Association: Servo enable control | Run settings | Effective | 0~41 | UInt16 |
| | | | | immediately | | |
| H03_03 | 0 | DI1 Logical selection: valid and logical | Run settings | Effective | 0~1 | UInt16 |
| | | | | immediately | | |
| H04_00 | 19 | DO1 association: Speed reaches output | Run settings | Effective | 0~19 | UInt16 |
| | | | | immediately | | |
| H04_01 | 0 | DO1 logic selection: conduction output when signal is | Run settings | Effective | 0~1 | UInt16 |
| | | valid, positive logic | | immediately | | |
| H06_02 | 0 | Speed Command Source: Internal Speed Command | Enable | Effective | 0~1 | UInt16 |
| | | | disconnect | immediately | | |
| H0C_13 | 1 | Parameter is saved to EEPROM and automatically set | Run settings | Effective | 0~1 | UInt16 |
| | | to 0 after success. Power to keep | | immediately | | |

Then communication controls the following parameter table object

| Parameter No | Function description | Modification | Effective | parameter range | Unit | Data type |
|--------------|---|--------------|-------------|-----------------|------|-----------|
| | | | way | | | |
| H06_03 | Sets the running speed command | Run settings | Effective | -6000~6000 | rpm | Int16 |
| | communication setting value | | immediately | | | |
| H06_05 | Set the speed to run the speedup time | Run settings | Effective | 0~65535 | ms | UInt16 |
| | | | immediately | | | |
| H06_06 | Set the deceleration time for the speed | Run settings | Effective | 0~65535 | ms | UInt16 |
| | operation | | immediately | | | |
| H06_18 | Speed reaches signal threshold | Run settings | Effective | 10~6000 | rpm | UInt16 |
| | | | immediately | | | |
| | Set 1 to enable the conduction motor to | Run settings | Effective | | | |
| 1102 02 | run; Set 0 to stop the motor | | immediately | 0.1 | | I Unt 16 |
| 105_05 | Or DI1 external signal, control motor | | | 0~1 | - | Unitro |
| | operation and stop | | | | | |

Note: The servo enable in this control scheme is not only the motor enable switch, but also the start speed running switch; If the running process is interrupted and enabled, the motor will stop according to the method of H05_05 parameter setting; If the current actual motor speed H0B_00>=H06_18, DO1 speed reaches the output effectively;

2: Communication control position operation

| Parameter No | Set | Function description | Modification | Effective | parameter | Data type |
|--------------|-------|---|--------------|-------------|-----------|-----------|
| | Value | | | way | range | |
| H02_00 | 1 | Control mode selection: position control | Enable | Effective | 0~2 | UInt16 |
| | | | disconnect | immediately | | |
| H03_02 | 1 | DI1 Association: Servo enable control | Run settings | Effective | 0~41 | UInt16 |
| | | | | immediately | | |
| H03_03 | 0 | DI1 Logical selection: valid and logical | Run settings | Effective | 0~1 | UInt16 |
| | | | | immediately | | |
| H03_04 | 28 | DI2 Association: Enable multi-bit running | Run settings | Effective | 0~41 | UInt16 |
| | | | | immediately | | |
| H03_05 | 0 | DI2 Logical selection: valid and logical | Run settings | Effective | 0~1 | UInt16 |
| | | | | immediately | | |
| H04_00 | 5 | DO1 association: Positioning is complete | Run settings | Effective | 0~19 | UInt16 |
| | | | | immediately | | |
| H04_01 | 0 | DO1 logic selection: conduction output when signal is | Run settings | Effective | 0~1 | UInt16 |
| | | valid, positive logic | | immediately | | |
| H05_00 | 2 | Position command source: internal multi-segment bit | Enable | Effective | 0~1 | UInt16 |
| | | command | disconnect | immediately | | |
| H11_00 | 0 | Multi-segment operation mode: The end of a single | Enable | Effective | 0~3 | UInt16 |
| | | cycle | disconnect | immediately | | |
| H11_01 | 1 | End segment of displacement command: run only 1 | Enable | Effective | 1~4 | UInt16 |
| | | segment; | disconnect | immediately | | |
| H0C_13 | 1 | Parameter is saved to EEPROM and automatically set | Run settings | Effective | 0~1 | UInt16 |
| | | to 0 after success. Power to keep | | immediately | | |

First, use the debugging software of the upper computer to set the following parameters in advance

Then communication controls the following parameter table object

| Parameter No | Function description | Modification | Effective | parameter range | Unit | Data type |
|---------------------|---|--------------|-------------|--------------------|----------|--------------------|
| | | | way | | | |
| H05 21 | Positioning Completion Signal Threshold | Run settings | Effective | 0- 65535 | Encoder | I Unt 16 |
| 1103_21 | Fositioning Completion Signal Threshold | | immediately | 0~05555 | Elicodei | Omrio |
| H11 04 | Set 0 relative displacement; set 1 absolute | Run settings | Effective | 0-1 | | I Unt 16 |
| 1111_04 | displacement | | immediately | 0~1 | - | Omro |
| Ш11 12 | Set the displacement amount of the run | Run settings | Effective | 000000 000000 | ram | Int ² 2 |
| III1_12 | Set the displacement amount of the run | | immediately | -99999999~99999999 | Thu | 1111.52 |
| Ш11 14 | Set the running speed | Run settings | Effective | 0 6000 | ma | I Unt 16 |
| ^{IIII} _14 | Set the running speed | | immediately | 0~0000 | IIIS | Omrio |
| 1111 15 | Set the appellantian and deceloration time | Run settings | Effective | 0 65525 | | I Unt 16 |
| пп_13 | Set the acceleration and deceleration time | | immediately | 0~03333 | IIIS | UIIIIO |
| | Set 1 motor to enable conduction; Set 0 to | Run settings | Effective | | | |
| H02 02 | enable the motor to be disconnected | | immediately | 0.1 | | I Unt 16 |
| 105_05 | Or DI1 external signal, control motor | | | 0~1 | - | Omrio |
| | enable on and off. | | | | | |
| | Set 1 more segment to start running; Let 0 | Run settings | Effective | | | |
| 402 05 | multibit stop | | immediately | 0.1 | | I Unt 16 |
| H03_05 | Or DI2 external signal, control multi-bit | | | 0~1 | - | Unito |
| | enable start and stop | | | | | |

Note: Multi-stage enabling is similar to multi-stage running switch. The multi-stage enabling motor starts to run according to the set position and speed, and the motor stops automatically after running. Running again requires re-enabling multibit enablement. If the multi-segment enable is disconnected during operation, the motor will stop immediately; If the current value of the current deviation counter H0B_15<H05_21, the output of DO1 is valid after the completion of DO1 positioning;

3: Communication control torque operation

First, use the debugging software of the upper computer to set the following parameters in advance

| Parameter No | Set | Function description | Modification | Effective | parameter | Data type |
|--------------|-------|---|--------------|-------------|-----------|-----------|
| | Value | | | way | range | |
| H02_00 | 2 | Control mode selection: torque control | Enable | Effective | 0~2 | UInt16 |
| | | | disconnect | immediately | | |
| H03_02 | 1 | DI1 Association: Servo enable control | Run settings | Effective | 0~41 | UInt16 |
| | | | | immediately | | |
| H03_03 | 0 | DI1 Logical selection: valid and logical | Run settings | Effective | 0~1 | UInt16 |
| | | | | immediately | | |
| H04_00 | 18 | DO1 association: Torque reaches output | Run settings | Effective | 0~19 | UInt16 |
| | | | | immediately | | |
| H04_01 | 0 | DO1 logic selection: conduction output when signal is | Run settings | Effective | 0~1 | UInt16 |
| | | valid, positive logic | | immediately | | |
| H0C_13 | 1 | Parameter is saved to EEPROM and automatically set | Run settings | Effective | 0~1 | UInt16 |
| | | to 0 after success. Power to keep | | immediately | | |

Then communication controls the following parameter table object

| Parameter No | Function description | Modification | Effective | parameter range | Unit | Data type |
|--------------|---|--------------|-------------|-----------------|------|-----------|
| | | | way | | | |
| H07_03 | Set the communication setting value of | Run settings | Effective | -3000~3000 | 0.1% | Int16 |
| | the running torque command | | immediately | | | |
| H07_19 | Set forward maximum speed limit for | Run settings | Effective | 0~6000 | rpm | UInt16 |
| | torque operation | | immediately | | | |
| H07_20 | Sets reverse maximum speed limit for | Run settings | Effective | 0~6000 | rpm | UInt16 |
| | torque operation | | immediately | | | |
| H07_21 | Set the torque to reach the reference value | Run settings | Effective | 0~3000 | 0.1% | |
| | | | immediately | | | |
| H07_22 | Set the torque to an effective value | Run settings | Effective | 0~3000 | 0.1% | |
| | | | immediately | | | |
| H07_23 | Set the torque to an invalid value | Run settings | Effective | 0~3000 | 0.1% | |
| | | | immediately | | | |
| | Set 1 to enable the conduction motor to | Run settings | Effective | | | |
| H03 03 | run; Set 0 to stop the motor | | immediately | 0-1 | | I Unt 16 |
| 105_03 | Or DI1 external signal, control motor | | | 0~1 | - | Unitro |
| | operation and stop. | | | | | |

Note: The servo enable in this control scheme is not only the motor enable switch, but also the switch to start the torque operation; If the running process is interrupted and enabled, the motor will stop according to the method of H05_05 parameter setting;

If the actual motor torque H0B_02>= $(H07_21+H07_22)$ DO1 torque reaches the output, it is effective; If the current motor actual torque H0B_02< $(H07_21+H07_23)$ DO1 torque reaches the output invalid;

Chapter 6 Application of multi-circle absolute value system

6.1 Application of the multi-turn absolute value system

Using the multi-turn absolute value system application, it is necessary to install a multi-turn absolute value encoder on the matched motor, which detects the bits within one rotation of the motor

The number of turns of the motor is also counted, and the maximum recording range is -32768-32767 turns; Multi-turn absolute encoders require external uninterruptible power supply in order for position data not to be lost. In the case of servo drive power, the driver is connected

The encoder extension cable provides power to the encoder, and the battery on the encoder extension cable provides power to the encoder in the case of power loss of the driver

No more than 2 years is recommended.

6.2 Fault Code ER.731/ ER.730/ ER.735

ER.731 (Multi-turn absolute encoder battery failure) is to remind the user that the multi-turn absolute encoder is powered off, the recorded number of turns data is lost, and it needs to be re-repeated Bit encoder H0D_20=2, if using absolute value positioning need to re-confirm the coordinate position; ER.731 (multi-turn absolute encoder battery failure)

1: Connect the motor, drive and extension cables at the first time, power on the drive, and the drive will alarm ER.731;

2: Forcibly replace the battery in the case of power loss of the driver, or the battery extension cable connected to the motor encoder is disconnected, the driver will alarm ER.731;

3: The battery connected to the encoder is damaged and cannot continue to provide power to the motor encoder, and the driver will alarm ER.731;

After ensuring that the battery can supply power to the multi-turn absolute encoder normally, the H0D_20=2 reset operation is performed.

| H0D_20 | Description | Absolute value encoder reset enabled | | Alter mode | Advanced configuration | factory default | 0 | Unit | - |
|--------|--------------------|---|---|------------------|-----------------------------|-----------------------|-------|-----------|--------|
| | Parameter range | 0 | 2 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 |

Set 0; Have no effect;

Set 1: Reset the internal fault information of the absolute encoder;

Set 2: Reset the internal fault information of absolute encoder + clear multi-circle data;

ER.730 (Multi-turn absolute encoder battery Warning), when the detected battery voltage is less than 3.0V to remind the user to replace the battery in time, otherwise the encoder data may be lost

To lose; For details about how to replace the battery, see the next section. When the battery is correctly replaced without affecting the recorded number of turns, this warning is automatically lifted without the need for an encoder reset; The wrong battery replacement method will cause the multi-turn absolute encoder to be powered off, and the recorded number of turns data will be lost. The driver will alarm ER.731

69

ER.735 (multi-turn absolute encoder number overflow), when the encoder multi-turn data positive revolution is greater than 32767 turns or reverse is less than -32768 will alarm; If multiple

In the case of linear continuous rotation, over a period of time, the number of turns will always exceed the upper limit or lower that the multi-turn absolute value encoder can count

Limit, can be H0A_36=1, shielding ring number overflow fault alarm;

| H0A_36 | Description | Absolute encoder fault shield selection | | Alter mode | Advanced configurat ion | factory default | 0 | Unit | - | | |
|--|-----------------|---|---|------------------|-------------------------------|-----------------------|-------|-----------|--------|--|--|
| | Parameter range | 0 | 3 | Effective way | with immediate effect | Adaptation pattern | P/S/T | Data type | UInt16 | | |
| Set 0: multi-turn absolute encoder normal application; | | | | | | | | | | | |
| Set 1: Screening coil overflow detection; | | | | | | | | | | | |

Set 2: Shield battery status detection

Set 3: Shielding coil overflow detection + battery status detection;

Note: When matching the motor with the absolute value of multiple turns, it does not use its absolute value function, and is only used as an incremental motor, it can be equipped with no battery requiring H0A_36=2 shielding

Check the battery status. The number of turns overflow detection is also not required. H0A_36=3 Number of turns overflow detection + battery status detection is also not required

6.3 Precautions for Replacing the absolute value encoder Battery

When do I need to replace the encoder battery?

1: The servo is in normal use, and the encoder cable has not been removed, if the alarm ER.730, it indicates a battery warning, reminding the user to replace the encoder in time. Or else

Loss of position data recorded by the encoder may occur;

2: The servo is in normal use, and the encoder cable has not been removed. If the alarm is sent to ER.731, it indicates that the battery is faulty and reminds the user that the encoder battery must be replaced. Encoder position data has been lost;

3: The encoder battery needs to be replaced immediately if the encoder battery is leaking, damaged, or bulging, to prevent the encoder position data from being lost due to battery loss.

How to properly replace the encoder battery

1: Ensure that power is generated in the driver and the encoder cable is normally connected to the driver; 2: Disconnect the drive, open the battery box cover in non-running state, take out the old battery, install the new battery;

3: The end of the replacement, ER.730 automatic release indicates that the encoder position data is not lost;

Note:

1: Recommended battery specifications: 3.6V 2500mAh;

2: Install a new battery pay attention to distinguish between positive and negative battery, generally red positive, black negative. The reverse connection of positive and negative poles may cause damage to the motor encoder; 3: Improper battery replacement causes the encoder to lose power abnormally, resulting in position data loss alarm ER.731 battery fault, need to be re-connected after the recovery

Reset encoder H0D_20=2. If absolute value positioning is used, the coordinate position needs to be reconfirmed.

Chapter 7 Alarm and handling

7.1-Status light and alarm information

AIMtor series products have a variety of alarm protection functions, through the body panel alarm code to view the fault information, can also connect to the host computer debugging software to view the more Detailed alarm information, according to the obtained alarm information to investigate the corresponding cause of alarm and solve

Fault alarm and treatment

1. Warning warning type, no fault signal is output, the warning is automatically lifted after the warning condition is not established, and no fault reset is required.

2. alarm fault type, will output a fault signal, need to reset the fault to remove the fault.

| Alarm | Alarm | Туре | Alarm warning | Possible causes | Solution |
|----------------------------|--------|----------------|---|--|---|
| message | code | | principle | | |
| Position overshoot | ER.B00 | Fault Alarm | In the position control mode, the position deviation is greater than the H0A-10 threshold | motor is blocked due to mechanical | Check the mechanical factors to ensure that the |
| | | | | motor does not respond to higher input pulse frequency | Reduce the input pulse frequency |
| | | | | When the motor starts and stops or reverses, the acceleration and deceleration are too fast and the motor cannot respond | Increase acceleration and deceleration time |
| | | | | motor selection is too small, and the torque is not enough, resulting in large position following error | Motor selection enlargement |
| | | | | Servo driver gain is low, motor response is slow | Increase the gain parameter value |
| | | | | Driver UVW output phase break or encoder break | Checking Cable connections |
| | | | | load inertia is large and the motor response is not timely | Appropriately increase the H0A-10 threshold |
| | | | | input power supply is unstable | Stable input power quality |
| Driver overvoltage | ER.400 | Fault Alarm | input voltage exceeds the allowable value | load inertia is large, and the motor | Increase acceleration and deceleration time to |
| | | | | generates regenerative energy when | smooth start and stop |
| | | | | starting and stopping, resulting in high | Regenerative braking resistance is added to |
| | | | | bus voltage | absorb regenerative energy |
| Driver undervoltag e | ER.410 | Fault Alarm | input voltage is lower than the allowable value | input power supply is unstable | Stable input power quality |
| | | | | input power is too small, resulting in insufficient power when the load is | Increase the input power |
| | | | | running and the voltage is lowered | |
| Motor overload | ER.620 | Fault Alarm | The overload energy exceeds the | load is too heavy, and the running torque of the motor exceeds the rated torque for a | Motor selection enlargemen |

Failure warning table

]

| Driver | | | allowable value of | long time | |
|----------|--------------|----------------------|----------------------------------|---|---|
| overload | | | the system | | |
| | | | | Start-stop commutation is too frequent or | Increase acceleration and deceleration time to |
| | | | | the load inertia is too large | smooth start and stop |
| | | | | Due to mechanical factors, the motor is blocked, resulting in excessive load during operation | Check the mechanical factors to ensure that the machine is smooth |
| | | | | gain adjustment is inappropriate or the rigidity is too strong, resulting in uncontrolled torque output | Reasonably adjusted gain |
| | | | | Driver UVW output phase break or encoder break | Checking Cable connections |
| Motor | or ER.630 | Fault R.630 Alarm | There are motion commands and no | motor is blocked due to mechanical factors Driver UVW output phase break or | Check the mechanical factors to ensure that the machine is smooth |
| B | | motion feedback | encoder break | Checking Cable connections | |

| Alarm warning message | Alarm code | Туре | Alarm warning principle | Possible causes | Solution |
|---|---------------|----------------|--|--|--|
| Driver | ED 201 | Fault Alarm | output current exceeds the hardware or software range | Improper gain adjustment or too rigid, resulting in uncontrolled current output | Reasonably adjusted gain |
| overcurrent | ER.201 | | | Driver UVW output phase break or encoder break | Checking Cable connections |
| | | Fault Alarm | | Transient load mutation | Check the mechanical factors to ensure that the machine is smooth |
| driver software | ER.207 | | | Driver output short-circuited, UVW cable short-circuited | Check the drive output and measure the motor cable |
| overflows | | | | Driver damage or motor coil short circuit | Check the motor coil to make sure there is no short circuit |
| Motor Overspeed | ER.500 | Fault Alarm | Motor running speed oversize value | The actual motor speed exceeds the maximum allowable value | Slow down |
| | | | | Ambient temperature is too high | Increase environmental cooling measures |
| motor or driver temperature is too high | ER.650 | Fault Alarm | Driver temperature detection exceeds allowable value | After overload, turn off the power to reset and restart repeatedly full load operation Long time full load operation causes | Motor selection is increased to avoid full load operation |
| | | | | the motor to overheat | |
| Parameters that require power off and restart (Warning) | ER.941 | Fault Alarm | Remind the user that the parameter value takes effect only after the power is powered on again | Alert the user that a parameter has been changed that will not take effect until power on again | After confirming that the modified parameter is the expected value, save it permanently, power off and restart the parameter to take effect, and the warning is automatically cleared |
| origin does not match | ER.668 | Fault Alarm | Return to the origin mode does not match | Origin resetting mode H05-31 selects 14/15/16 single-turn electrical resetting | If H05-31 single turn back to zero mode, H05-30 should choose electrical return to zero |

[74]

| | mode, while H05-30 chooses origin | trigger |
|--|--|--|
| | resetting control | |
| | Origin recovery mode H05-31 Select 6/7/10/11, H05-36 mechanical origin | Change the direction of the offset value of the origin of the H05-36 parameter |
| | error, (positive = positive direction, negative = negative direction) | Make it move in the right direction offset position |
| | Origin resetting mode H05-31 selects either an external origin switch condition or an over-the-range limit switch condition but does not associate the condition to the corresponding physical DI pin | Assign the corresponding DI function to the physical DI input port based on the origin restore mode selected by H05-31 |
| | In the process of return to zero, the external origin switch and the over-range limit switch signal are connected at the same time, or the positive and negative over-range limit signal are connected at the same time | Check the external origin switch or POT/NOT limit switch for simultaneous conduction |

| Alarm warning | Alarm | Туре | Alarm | Possible causes | Solution |
|---------------------------|--------|----------------|--|--|---|
| message | code | | warning | | |
| | | | principle | | |
| Back to origin timeout | ER.601 | Fault Alarm | Origin return The origin was not found within the H05_35 time limit | When using the origin return function, the distance from the origin is far away, and the origin is not found within the specified time | Increase the H05_33/H05_34 origin search speed to find the origin in the specified time |
| | | | | external origin switch or deceleration point has no signal, so the origin can not be found | Check whether the external origin switch or deceleration point switch signal is normal |
| | | | | When Z phase is used to return to zero, a limit is encountered, resulting in a logical conflict that keeps finding the origin | Check whether the POT/NOT position of the limit switch is reasonable and change the installation position of the limit switch |
| | ER.A33 | Fault Alarm | Encoder | encoder wire is broken or not contacted well, resulting in the driver not recognizing the encoder signal | Check the encoder connection cables Check the encoder connection port |
| Encoder fault | | | communicatio | encoder is faulty or damaged | Replace motor encoder |
| | | | n failure | encoder cable is interfered with externally; | motor drive is properly grounded, and the |
| | | | | Cause the driver to not recognize the | encoder cable is isolated from the high-current |
| | | | | encoder signal | and high-power source |
| EEPROM parameter | ER.101 | Fault Alarm | Fault EEPROM Alarm Wrong | system detected very frequent parameter changes written to the EEPROM in a short time | Check the communication mode and modify parameters to avoid repeatedly permanently saving parameters into EEPROM |
| error | | | | Internal parameters are abnormal. Procedure | All factory Settings need to be restored |
| | | | | Hardware EEPROM chip damage | Replace hardware |

(75 **)**

| MCU program exception | ER.105 | Fault Alarm | internal program is abnormal. Procedure | Internal watchdog trigger | If the power-off is not resolved, return it to the factory for testing |
|--------------------------|--------|----------------|---|---|--|
| Other alarms or | ER.730 | Fault Alarm | ncoder battery warning | For motors using multi-turn absolute encoders, the externally supplied battery voltage is below 3.0V Note: This warning message, the fault signal is not output | Replace the encoder battery in time to ensure that the battery voltage is greater than 3.0V, please refer to Chapter 6 for details |
| | ER.731 | Fault Alarm | Encoder battery failure | In a motor using a multi-turn absolute encoder, the encoder is powered off, resulting in loss of the number of position turns | Check the encoder battery power cable, Check the encoder battery, Please refer to Chapter 6 for details |
| | ER.735 | Fault Alarm | Multiple absolute number of turns overflow | For a motor using a multi-turn absolute encoder, the number of turns counts in the range of positive revolutions greater than 32767 or reversals less than -32768 | Avoid turning count out of range Continuous rotation can mask this alarm, Please refer to Chapter 6 for details |
| | ER.950 | Fault Alarm | forward overdrive POT is connected | To remind that the forward overrange POT limit signal is on, the forward motion will be restricted; | his warning is automatically lifted when the forward overrange POT limit signal is disconnected |
| | ER.952 | Fault Alarm | Negative overdrive is NOT connected | The reminder that the negative overrange POT limit signal is on will limit the negative movement | This warning is automatically lifted when the negative overreach NOT limit signal is disconnected |
| warnings | ER.130 | Fault Alarm | DI terminal function is reassigned | Multiple DI terminals are assigned to the same DI input function, resulting in repeated assignment | reassignment DI function is associated with an input terminal |
| | ER.900 | Fault Alarm | Scram signal in effect | DI function stops in an emergency. The associated DI connection takes effect | DI associated with emergency stop is disconnected, and this warning is automatically cleared |
| | | | | internal emergency stop of the upper computer takes effect | internal emergency stop of the upper computer is disconnected, and this warning is automatically lifted |
| | ER.234 | Fault Alarm | Motor racing | Rapid motor shaft movement was detected during power-on initialization, and there is a hidden danger. | When powering on, ensure that the motor shaft is free of external interference, so that it is stationary |
| | ER.102 | Fault Alarm | Parameter EEPRM exception | Specifications Unregistered Hardware The | Motor drive is not registered, returned to factory |
| | Er.104 | Fault Alarm | Imported parameter area EEPRM exception | EEPROM chip is damaged | registration, hardware EEPROM chip |